




MOTOROLA

DIGITAL WIRELESS
TELEPHONE

User's Guide >

Welcome

Welcome to the world of Motorola digital wireless communications! We are pleased that you have chosen the Motorola V60i TDMA wireless phone.



Personal Communications Sector
600 North U.S. Highway 45
Libertyville, Illinois 60048

1-800-331-6456 (United States)
1-888-390-6456 (TTY/TDD United States)
1-800-461-4575 (Canada)

www.motorola.com (United States)
www.motorola.ca (Canada)

MOTOROLA, the Stylized M Logo and all other trademarks indicated as such herein are trademarks of Motorola, Inc. ® Reg. U.S. Pat. & Tm. Off. TrueSync, Sidekick, Starfish, and the Stylized Starfish Logo are registered trademarks of Starfish Software, Inc., a wholly owned independent subsidiary of Motorola, Inc. All other product or service names are the property of their respective owners.

© 2001, 2002 Motorola, Inc. All rights reserved.

Software Copyright Notice

The Motorola products described in this manual may include copyrighted Motorola and third party software stored in semiconductor memories or other media. Laws in the United States and other countries preserve for Motorola and third party software providers certain exclusive rights for copyrighted software, such as the exclusive rights to distribute or reproduce the copyrighted software. Accordingly, any copyrighted software contained in the Motorola products may not be modified, reverse-engineered, distributed, or reproduced in any manner to the extent allowed by law. Furthermore, the purchase of the Motorola products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents, or patent applications of Motorola or any third party software provider, except for the normal, non-exclusive, royalty-free license to use that arises by operation of law in the sale of a product.

Manual number: 6809449A10-A

Cover number: 8988485L49-O

Menu Map

Main Menu

- Recent Calls
 - Received Calls
 - Dialed Calls
 - Notepad
 - Call Times
- Phonebook
- Datebook
- Radio
- Messages
 - Create Message
 - Voicemail
 - Text Msgs
 - Quick Notes
 - Outbox
 - Drafts
- Ring Styles
 - Style
 - Style Detail
 - My Tones
- Shortcuts
- Voice Notes
- Calculator
- Games
- Settings
 - (see next page)

This is the standard phone menu layout. You or your service provider may have changed the menu layout or changed some feature names. Not all features may be available for all users.

For example, the **Radio** feature on the main menu (left) is displayed only when the optional FM Stereo Radio Headset accessory is plugged into the accessory connector port on your phone (see phone illustration, page 1).

Shortcuts
Change display zoom: Press , then press and hold
Change ringer alert: Press down volume key to switch to vibrate alert, then silent alert. Press up volume key to reset ring alert.
Display my phone number: Press
Go to dialed calls list: Press
Exit menu system: Press
Open phonebook: Press down
Create phonebook entry: Press up

Settings Menu

- **Phone Status**
 - My Tel. Number
 - Active Line
 - Battery Meter
- **In-Call Setup**
 - In-Call Timer
 - Answer Options
- **Security**
 - Phone Lock
 - Lock Application
 - Talk Secure
 - Restrict Calls
 - New Passwords
- **Other Settings**
 - Personalize
 - Main Menu
 - Keys
 - Initial Setup
 - Time and Date
 - Backlight
 - Status Light
 - Zoom
 - TTY Setup
 - Scroll
 - Animation
 - Language
 - Contrast
 - DTMF
 - Master Reset
 - Master Clear
- Network
- Car Settings
- Headset

Contents

Menu Map	3
About This Guide	10
Safety and General Information	11
Getting Started	17
What's in the Box?.....	17
Installing the Battery	17
Charging the Battery	18
Changing the Convertible Covers	19
Turning Your Phone On.....	21
Making a Call.....	22
Ending a Call.....	22
Answering a Call	22
Seeing Your Phone Number	23
About Your Phone	24
Using the Display	24
Zooming In and Out.....	26
Using the Status Light.....	26
Adjusting Volume.....	27
Using the Smart Key	27
Using the External Display	28
Battery Use	29
Making and Answering Calls	31
Redialing a Number.....	31
Using Caller ID	31
Using Talk Secure	31
Returning an Unanswered Call.....	32
Calling an Emergency Number.....	32
Turning Off a Call Alert	33

Cancelling an Incoming Call	33
Calling With Speed Dial	34
Calling With One-Touch Dial	34
Calling a Number In a Text Message	34
Additional Calling Features	35
Using Features While On a Call	37
Using Call Waiting	37
Making a Three-Way Call	37
Additional On-Call Features	38
Using the Menu	39
Navigating to a Feature	39
Selecting a Feature Option	40
Entering Feature Information	41
Entering Text	43
Choosing a Text Mode	43
Using Tap Method	44
Using Symbol Mode	47
Using iTAP™ Software Predictive Text Entry Method	48
Menu Feature Descriptions	52
Recent Calls	62
Viewing Received Calls or Dialed Calls	62
Using the Notepad	64
Viewing and Resetting Call Timers	65
Phonebook	67
Viewing Entry Details	67
Creating a Phonebook Entry	68
Storing a PIN Code With a Phone Number	70
Recording a Voice Name For a Phonebook Entry	72
Dialing a Phonebook Entry	73
Storing Longer Numbers	74

Editing a Phonebook Entry	75
Deleting a Phonebook Entry	75
Setting the Primary Number for a Phonebook Entry	76
Checking Phonebook Capacity	76
Sorting the Phonebook List	77
Synchronizing with TrueSync Software	78
Datebook	79
Week View	79
Day View	80
Event View	80
Adding a Datebook Event	81
Changing Event Information	81
Copying an Event	82
Deleting an Event	83
Synchronizing with TrueSync Software	83
Radio	84
Turning the Radio On and Off	84
Tuning a Station	85
Storing a Preset	85
Selecting a Preset	85
Sending and Receiving Calls With the Radio On	85
Messages—Voicemail	87
Storing Your Voicemail Number	87
Receiving a Voicemail Message	88
Listening to a Voicemail Message	88
Messages—Text	89
Setting Up the Text Message Inbox	89
Receiving a Text Message	90
Reading, Locking, or Deleting a Text Message	91
Storing Sounds	93

Sending a Text Message.....	94
Sending a Quick Note Text Message	97
Viewing the Status of Sent Text Messages.....	98
Ring Styles	99
Selecting a Ring Style.....	99
Customizing a Ring Style	99
Using My Tones	101
Setting Reminders	107
Shortcuts.....	109
Standard Shortcuts.....	109
Creating a Shortcut.....	110
Using Shortcuts	111
Voice Notes.....	113
Recording a Voice Note	113
Viewing the Voice Notes List.....	114
Playing a Voice Note.....	114
Locking and Unlocking a Voice Note.....	117
Deleting a Voice Note	118
Calculator	119
Calculating Numbers.....	119
Converting Currency.....	121
Games	122
Playing a Game	122
Blackjack.....	122
Falling Numbers	124
Video Poker.....	125
Adjusting Your Settings.....	127
Reordering Menu Items	127
Customizing a Soft Key Function	127
TTY Operation	128
Hands-Free Use	130

Data Calls	134
Making a Cable Connection	134
Synchronizing Data	136
Sending a Data Call	136
Receiving a Data Call	137
Security	139
Assigning a New Code or Password	139
If You Forget a Code or Password	140
Locking and Unlocking Your Phone	141
Restricting Calls	142
Activating Talk Secure	143
Troubleshooting	144
Specific Absorption Rate Data	152
Additional Health and Safety Information	154
Warranty	162
Product Registration	167
Export Law Assurances	167
Index	168
Wireless Phone Safety Tips	179

About This Guide

This user guide introduces you to the many features in your Motorola wireless phone.

Navigating To a Menu Feature

Use the menu system to access your phone's features. This guide shows you how to select a menu feature as follows:

Find the Feature

 > Messages
 > Create Message

This example shows that from the idle display, you must press , scroll to and select **Messages** from the main menu, then scroll to and select **Create Message**.

Optional Features



This label identifies an optional network or subscription-dependent feature that may not be offered by all service providers in all geographical areas. Contact your service provider for more information.

Optional Accessories



This label identifies a feature that requires an optional Motorola Original™ accessory.

Safety and General Information

**IMPORTANT INFORMATION ON SAFE AND EFFICIENT OPERATION.
READ THIS INFORMATION BEFORE USING YOUR PHONE.**

The information provided in this document supersedes the general safety information contained in user guides published prior to July 2000. For information regarding radio use in a hazardous atmosphere please refer to the Factory Mutual (FM) Approval Manual Supplement or Instruction Card, which is included with radio models that offer this capability.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Operational Characteristics

Your phone contains a transmitter and a receiver. When it is ON, it receives and transmits radio frequency (RF) energy. The phone operates in the frequency range of 824 MHz to 849 MHz in analog mode and 1850 MHz to 1910 MHz in digital mode.

When you communicate with your phone, the system handling your call controls the power levels at which your phone transmits. The output power level typically may vary over a range from 0.04 watts to 0.49 watts in analog mode and 0.0 watts to 0.57 watts in digital mode.

Exposure To Radio Frequency Energy

Your Motorola phone is designed to comply with the following national and international standards and guidelines regarding exposure of human beings to radio frequency electromagnetic energy:

- United States Federal Communications Commission, Code of Regulations; 47 CFR part 2 sub-part J

- American National Standards Institute (ANSI) / Institute of Electrical and Electronic Engineers (IEEE) C95.1-1992
- Institute of Electrical and Electronic Engineers (IEEE) C95.1-1999 Edition
- National Council on Radiation Protection and Measurements (NCRP) of the United States, Report 86, 1986
- International Commission on Non-Ionizing Radiation Protection (ICNIRP) 1998
- Ministry of Health (Canada) Safety Code 6. Limits of Human Exposure to Radiofrequency Electromagnetic Fields in the Frequency Range from 3 kHz to 300 GHz, 1999
- Australian Communications Authority Radiocommunications (Electromagnetic Radiation-Human Exposure) Standard 1999

To assure optimal phone performance and make sure human exposure to radio frequency electromagnetic energy is within the guidelines set forth in the above standards, always adhere to the following procedures:

Portable Phone Operation and EME Exposure

Antenna Care

Use only the supplied or an approved replacement antenna.

Unauthorized antennas, modifications, or attachments could damage the phone and may violate FCC regulations.

Do NOT hold the antenna when the phone is in use. Holding the antenna affects call quality and may cause the phone to operate at a higher power level than needed.

Phone Operation

When placing or receiving a phone call, hold your phone as you would a wireline telephone. **Speak directly into the microphone.**

Body-Worn Operation

To maintain compliance with FCC/Health Canada RF exposure guidelines, if you wear a phone on your body when transmitting, always place the phone in a Motorola-supplied or approved clip, holder, holster, case, or body harness for this product. Use of non-Motorola-approved accessories may exceed FCC/Health Canada RF exposure guidelines. If you do not use one of the Motorola-supplied or approved body-worn accessories, and are not using the phone held in the normal use position, **ensure the phone and its antenna are at least one inch (2.5 centimeters) from your body when transmitting.**

Data Operation

When using any data feature of the phone, with or without an accessory cable, **position the phone and its antenna at least one inch (2.5 centimeters) from your body.**

Approved Accessories

For a list of approved Motorola accessories, visit our website at www.mot.com.

Electromagnetic Interference/Compatibility

Note: Nearly every electronic device is susceptible to electromagnetic interference (EMI) if inadequately shielded, designed, or otherwise configured for electromagnetic compatibility.

Facilities

To avoid electromagnetic interference and/or compatibility conflicts, turn off your phone in any facility where posted notices instruct you to do so. Hospitals or health care facilities may be using equipment that is sensitive to external RF energy.

Aircraft

When instructed to do so, turn off your phone when on board an aircraft. Any use of a phone must be in accordance with applicable regulations per airline crew instructions.

Medical Devices

Pacemakers

The Advanced Medical Technology Association recommends that a minimum separation of 6 inches (15 centimeters) be maintained between a handheld wireless phone and a pacemaker. These recommendations are consistent with the independent research by, and recommendations of, the United States Food and Drug Administration.

Persons with pacemakers should:

- ALWAYS keep the phone more than six inches (15 centimeters) from your pacemaker when the phone is turned ON.
- NOT carry the phone in the breast pocket.
- use the ear opposite the pacemaker to minimize the potential for interference.
- turn OFF the phone immediately if you have any reason to suspect that interference is taking place.

Hearing Aids

Some digital wireless phones may interfere with some hearing aids. In the event of such interference, you may want to consult your hearing aid manufacturer to discuss alternatives.

Other Medical Devices

If you use any other personal medical device, consult the manufacturer of your device to determine if it is adequately shielded from RF energy. Your physician may be able to assist you in obtaining this information.

Safety and General Use While Driving

Check the laws and regulations on the use of phones in the area where you drive. Always obey them.

When using your phone while driving, please:

- give full attention to driving and to the road.
- use hands-free operation, if available.
- pull off the road and park before making or answering a call if driving conditions so require.

Operational Warnings

For Vehicles With an Air Bag

Do not place a portable phone in the area over an air bag or in the air bag deployment area. Air bags inflate with great force. If a portable phone is placed in the air bag deployment area and the air bag inflates, the phone may be propelled with great force and cause serious injury to occupants of the vehicle.

Potentially Explosive Atmospheres

Turn off your phone prior to entering any area with a potentially explosive atmosphere, unless the phone is a model specifically identified as being "Intrinsically Safe." Do not remove, install, or charge batteries in such areas. Sparks in a potentially explosive atmosphere can cause an explosion or fire resulting in bodily injury or even death.

Note: The areas with potentially explosive atmospheres referred to above include fueling areas such as below decks on boats, fuel or chemical transfer or storage facilities, areas where the air contains chemicals or particles, such as grain, dust, or metal powders, and any other area where you would normally be advised to turn off your vehicle engine. Areas with potentially explosive atmospheres are often but not always posted.

Blasting Caps and Areas

To avoid possible interference with blasting operations, turn OFF your phone when you are near electrical blasting caps, in a blasting area, or in areas posted: "Turn off two-way radio." Obey all signs and instructions.

Operational Cautions

Antennas

Do not use any portable phone that has a damaged antenna. If a damaged antenna comes into contact with your skin, a minor burn can result.

Batteries

All batteries can cause property damage and/or bodily injury such as burns if a conductive material such as jewelry, keys, or beaded chains touches exposed terminals. The conductive material may complete an electrical circuit (short circuit) and become quite hot. Exercise care in handling any charged battery, particularly when placing it inside a pocket, purse, or other container with metal objects.

Getting Started

What's in the Box?



Getting Started

Your wireless phone typically comes equipped with a battery and a charger. Other accessory options can customize your phone for maximum performance and portability.

To purchase Motorola Original™ accessories, contact the Motorola Customer Call Center at 1-800-331-6456 in the United States or 1-800-461-4575 in Canada.

Installing the Battery


You must install and charge the battery to use your phone.



Your phone is designed to be used only with Motorola Original batteries and accessories. We recommend that you store batteries in their protective cases when not in use.

Do This


- 1 Remove the battery from its protective clear plastic case.
- 2 If necessary, push down the battery door release latch and lift the door off of the phone.






Do This

- 3 Insert the battery, printed arrow first, **under the tab** at the top of the battery compartment and push down.



- 4 Insert the ridge at the bottom of the battery door into the base of the phone, then push the door down and snap it into place.




Charging the Battery

New batteries are shipped partially charged. Before you can use your phone, you need to install and charge the battery, as indicated by the following instructions. Some batteries perform best after several full charge/discharge cycles.

Do This

- 1 Plug the travel charger into your phone with the release tab facing up.



Do This

- 2** Plug the other end of the travel charger into the appropriate electrical outlet.
- 3** When your phone indicates that the battery is fully charged (**Charge Complete**), press the release tab and remove the travel charger.

**Notes:**

- When you charge the battery, the battery level indicator in the upper right corner of the display shows how much of the charging process is complete.
- If the battery charge drops too low, your phone may power off during a call, even when the charger is connected. To avoid this possibility, do not make calls while charging the battery.

Changing the Convertible Covers



You can replace the flip cover and battery cover on your phone to personalize its appearance.

Matching front and back cover sets are available in a variety of colors and designs.


Your phone is designed to be used only with Motorola Original accessories. See your Motorola retailer for these convertible covers.



Remove a Flip Cover

Do This


- 1 Open your flip phone *half way*.
- 2 Press in the tiny silver release button with your fingernail. This button is on the side of the top half of the phone.
- 3 While pressing the silver button in, slide the cover off the phone.



Attach a Flip Cover

Do This

- 1 Close your flip phone.
- 2 Line up the ridges on each side of the cover so that they align with the slots on the phone.



- 3 Slide the cover onto the phone until it snaps into place.

Turning Your Phone On

Do This	To
1 Open your phone	expose the keypad
2 Press and hold 	turn on your phone
 Power key	
3 If necessary, enter your four-digit unlock code and press 	unlock your phone The unlock code is originally set to 1234. Your service provider may change this number before you receive your phone.

Note: At startup, you are given the option to personalize your phone. Select **YES** () to set personal phone options, or **NO** () to go to the idle display. For more information, see "Personalize" on page 57.





Making a Call

Press	To
1 keypad keys	dial the phone number
2	Tip: If you make a mistake, press DELETE () to delete the last digit, or press and hold DELETE () to clear all digits. make the call

Ending a Call

Press	To
	end the call

Answering a Call

When you receive a call, your phone rings and/or vibrates and displays an incoming call message.

Press	To
or ANSWER ()	answer the call

Tip: If your phone is locked, you must unlock it to answer the call.

Seeing Your Phone Number

Press



To

see your phone number




Getting Started

About Your Phone

See page 1 for a basic phone diagram.

Using the Display



The *idle display* is the standard display that you see when you are *not* on a call or using the menu.

Labels at the bottom corners of the display show the current soft key functions. A ☰ (menu) indicator at the bottom center of the display indicates that you can press ☰ to enter the main menu.

❶ Signal Strength Indicator Vertical bars show the strength of the network connection. You cannot make or receive calls when the  (no signal) indicator is displayed.

 **❷ Digital (□) or Analog (▨) Signal Indicator** Shows whether you are receiving a digital or analog signal.

❸ In Use Indicator Shows that a call is in progress.

 **❹ Roam Indicator** Shows that your phone is seeking or using another network system outside your home network.

 **❺ Message Waiting Indicator** Appears when you receive a text message.

 **❻ Voice Message Waiting Indicator** Appears when you receive a voicemail message.

❼ Battery Level Indicator Vertical bars show the battery charge level. Recharge the battery when you see **Low Battery** and hear the low battery alert.

 **❽ Active Line Indicator** Shows the current active phone line.

❾ Menu Indicator Indicates that you can press  to enter the main menu or open a feature sub-menu.





⑩ Ring Style Indicator Shows the ring style setting.

= loud ring

= soft ring

= vibrate

= vibrate and ring

= silent


Zooming In and Out

Press and release , then press and hold to zoom in and out on the display. Zoom in to increase text size, zoom out to display more information.

You can also zoom in and out from the menu. See page 58.

Using the Status Light

The status light shows when you have an incoming call or message, or when your phone is *roaming* (using a non-home system).



Indication	Status
alternating red/green	incoming call
flashing green	in service, home system
flashing yellow	roaming, non-home system
flashing red	no service


The status light initially is turned off to extend battery life. To turn it on, see "Initial Setup" on page 58.

Note: Turning on the status light will substantially reduce your phone's *standby time*, the length of time that your phone's battery retains power when the phone is turned on but is not in use.

Adjusting Volume

Press the up and down volume keys to:


- increase and decrease earpiece volume during a call
- increase and decrease the ringer volume setting when the idle display is visible (flip must be open)



Tip: At the lowest volume setting, press the down volume key once to switch to vibrate alert. Press it again to switch to silent alert. Press the up volume key to cycle back to vibrate alert, then ring alert.

Using the Smart Key

The smart key gives you another way to perform many basic phone functions. It anticipates the next action you are likely to perform. For example, when you highlight a menu item,





you can press the smart key to select it. You can use the smart key to make and end calls, toggle features on and off, and open your phonebook. The smart key usually performs the same function as the right soft key (○).

Note: The smart key provides an optional way to do some things faster. It is never *the only way* to perform a task.

Using the External Display

When the flip is closed, the external display shows the time and date. It also displays messages to notify you of incoming calls and other events. You can perform the following functions in the external display.

Set Phone Ring Style

Press	To
1 volume keys	scroll to Style
2 smart key	select a ring style
3 volume keys	return to the idle display

Return an Unanswered Call

Your phone keeps a record of your unanswered calls and displays **X Missed Calls** in the external display.

Press	To
1 smart key	see the received calls list
2 volume keys	scroll through the list and select a call to return
3 smart key	make the call

Note: Because the microphone and earpiece are unavailable when the phone is closed, you must use a headset or other hands-free device with this feature.

Battery Use

Battery performance depends on many factors, including your wireless carrier's network configuration; signal strength; the temperature at which you operate your phone; the features and/or settings you select and use; and your voice, data, and other application usage patterns.



Battery Care

Caution: To prevent injuries or burns, do not allow metal objects to contact or short-circuit the battery terminals.

To maximize your battery's performance:

- Always use Motorola Original™ batteries and battery chargers. The phone warranty does not cover damage caused from using non-Motorola batteries and/or battery chargers.
- New batteries or batteries that have been stored for long periods of time may require a longer charge time.
- Maintain the battery at or near room temperature when charging.
- Do not expose batteries to temperatures below -10°C (14°F) or above 45°C (113°F). Always take your phone with you when you leave your vehicle.



- When you do not intend to use a battery for a while, store it uncharged in a cool, dark, dry place, such as a refrigerator.
- Over extended periods of time, batteries gradually wear down and require longer charging times. This is normal. If you charge your battery regularly and notice a decrease in talk time or an increase in charging time, then it is probably time to purchase a new battery.



The rechargeable batteries that power this product must be disposed of properly and may need to be recycled. Refer to your battery's label for battery type. Contact your local recycling center for proper disposal methods. Never dispose of batteries in a fire because they may explode.

Extending Battery Life

- **Turn off the status light**

The status light uses power. To turn it off, see "Initial Setup" on page 58.

- **Turn off the display backlight**

The backlight uses power. To turn it off, see "Initial Setup" on page 58.

- **Minimize keypad-intense functions**

Activities that require intensive keystroke use (such as playing a game or using messaging) reduce your phone's talk and standby time.

Making and Answering Calls

For basic instructions on how to make a call, end a call, and answer a call, see page 22.

Redialing a Number

If you hear an ordinary busy signal:

Press	To
1 	hang up
2 	redial the busy number



Using Caller ID



Calling line identification (caller ID) displays the phone number for incoming calls.

The phone displays the caller's name when the name is stored in your phonebook, or **Incoming Call** when caller ID information is not available.

Using Talk Secure

When *talk secure* is activated, your phone always tries to use a high-security connection to prevent others from intercepting your calls. To activate talk secure, see page 143.

If a high-security connection is not available, your phone uses a standard connection and displays **Line Not Secure**. This message does not appear when caller ID or other information is displayed.

Returning an Unanswered Call

Your phone keeps a record of your unanswered calls, and displays:

- the  (missed call) indicator
- **X Missed Calls Y Unknown**, where **X** is the total number of missed calls and **Y** is the number of missed calls with no caller ID information

Press	To
1 	see the received calls list
2 	select a call to return
3 	make the call

Calling an Emergency Number

Your service provider programs one or more emergency phone numbers, such as 911, that you can call under any circumstances, even when your phone is locked.

Note: Emergency numbers vary by country. Your phone's preprogrammed emergency number(s) may not work in all locations, and sometimes an emergency call cannot be

placed due to network, environmental, or interference issues.

Press	To
1 keypad keys	dial the emergency number
2 	call the emergency number

Turning Off a Call Alert

You can turn off your phone's incoming call alert before answering the call.

Press	To
either volume key	turn off the alert

Cancelling an Incoming Call

While the phone is ringing or vibrating:

Press	To
 or 	cancel the incoming call



Depending on your phone settings and/or service subscription, the call may be forwarded to another number, or the caller may hear a busy signal.



Calling With Speed Dial

Each entry you store in your phonebook is assigned a unique *speed dial* number. To speed dial a phonebook entry:

Press	To
1 keypad keys	enter the speed dial number for the entry you want to call
2 	submit the number
3  	call the entry

Calling With One-Touch Dial

To call phonebook entries 1 through 9, just press and hold the one-digit speed dial number for one second.

We recommend that you reserve phonebook entry 1 (speed dial number 1) for storing and dialing your voicemail number. In many cases, your service provider has already done this for you. If necessary, see page 68 to store your voicemail number for one-touch dial access.

Calling a Number In a Text Message



To call a phone number embedded in a text message that you receive, highlight or open the message and then:

Press	To
1 	open the Text Msg Menu
2 	scroll to Call Back
3 SELECT 	call the number


Additional Calling Features

While dialing (with digits visible in the display), open the Dialing Menu to perform the following tasks:

Press	To
 > Attach Number	attach a number from the phonebook or recent call lists
 > Insert Pause	insert a p (pause) character For more information, see page 70.
 > Insert Wait	insert a w (wait) character For more information, see page 70.
 > Insert 'n'	insert an n (number) character For more information, see page 70.
 > Send Message	open a new text message with the number in the To field



You can also call a number using these features:

Do This	To Call
<p>Press and release the voice key, then say a voice name</p>  <p>The diagram shows a standard phone keypad with a 'Voice key' highlighted. The key is located at the top center of the keypad, just below the 'END' key. It has a small speech bubble icon above it. The keypad also includes a 'MENU' key at the top left, a central navigation pad with up, down, left, and right arrows, and a 'SEND' key at the top right. Below the keypad are three rows of numeric keys: '1-2', '3 ABC', and '4 DEF' on the first row; '5 GHI', '6 JKL', and '7 MNO' on the second row; and '0' and '# MNDO' on the third row.</p>	<p>a phonebook entry using voice dial To record a voice name, see page 72.</p>
<p>Press MENU > Recent Calls > Received Calls or Dialed Calls > <i>entry to call</i></p>	<p>a missed call, or a recent received or dialed call</p>

Using Features While On a Call

Using Call Waiting



When you are on a call, an alert tone sounds to indicate that you have received a second call.

Press	To
1 (SND)	answer the new call
2 (SND)	switch back to the first call

Making a Three-Way Call



During a call, you can call and connect a third party for a three-way call. You cannot do this if you already have a call on hold.

Press	To
1 keypad keys	dial the third party's number
2 (SND)	call the number
3 (SND)	connect the two calls
4 (END)	end the entire call



Additional On-Call Features



Press	To
MUTE (○) (if available) or [MENU] > Mute	mute the call
SPEAKER (○) (if available) or [MENU] > Spkrphone On	activate an attached speakerphone during an active call
[MENU] > My Tel. Number	see your phone number
[MENU] > Send Tones	send a number to the network as DTMF tones Note: This option appears only when you enter or select a number during a call.
[MENU] > TTY Mode	change to TTY mode to use your phone with a TTY device
[MENU] > Received Calls or Dialed Calls	view recent received or dialed call numbers
[MENU] > Messages	view or send messages
[MENU] > Datebook	view datebook entries
[MENU] > Other Information	view phone specifications

Using the Menu

Navigating to a Feature

Use these keys to move through the menu system:

Menu Key

Enter menu system, or open a sub-menu, when  appears in bottom center of display.

Left Soft Key

Perform function shown in lower left corner of display (usually **EXIT** or **BACK**).

Volume Keys

Scroll up or down through menus and lists.

End Key

Exit menu system without making changes, return to idle display.

Right Soft Key


Perform function shown in lower right corner of display (usually **SELECT** the highlighted menu item).

Scroll Key

Scroll up or down through menus and lists. From idle display, press up or down to open phonebook.

and


Cycle through and set the value of the highlighted menu item.



Selecting a Feature Option

Some features require you to select an item from a list:

Press BACK (⌚) to go back to the previous screen.



Highlighted item

Press MENU (MENU) to open the sub-menu.

Press VIEW (⌚) to view details of the highlighted item.


- Press ⌚ to scroll up or down to highlight the item you want.
- In a numbered list, press a number key to highlight the item.
- In an alphabetized list, press a key multiple times to cycle through the letters on the key and highlight the closest matching list item.



Entering Feature Information

Some features require you to enter information:

Press  to scroll down to additional items.



Highlighted item

Press **CANCEL** () to exit without making changes.
DONE () appears when you enter or edit information.

Press **CHANGE** () to edit the information.

- Enter numbers or text with the keypad.
- When an item has a list of possible values, press  or  to scroll through and select a value.
- When an item has a list of possible numeric values, press a number key to set the value.
- If you enter or edit information and do not want to save your changes, press  to exit without saving.



The message center lets you compose and send text messages. A *flashing cursor* shows where text will appear:

Flashing cursor indicates insertion point.



Press **CANCEL** (○) to exit without making changes.

Press **BROWSE** (○) to view and insert a quick note.

Press **MENU** (○) to open the sub-menu.

When you enter text using the standard tap method, the flashing cursor changes to a *block cursor*, and the soft key functions change:

Block cursor indicates current highlighted character.



After two seconds, the block cursor reverts to a flashing cursor and moves to the next position.

Press **OK** (○) to accept and store the text.

Press **DELETE** (○) to delete the character to the left of the insertion point.



Entering Text

Multiple text entry methods make it easy for you to enter names, numbers, and messages on your phone.



Choosing a Text Mode

Press from any text entry screen to select a text mode:

- iTAP** Let the phone predict each word as you enter it. See page 48.
- Tap Method** Enter letters, numbers, and symbols by pressing a key one or more times. See page 44.
- Numeric** Enter numbers only.
- Symbol** Enter symbols only. See page 47.
- Browse** Browse your phonebook or recent call lists to select a name or number.

Note: The text mode you select remains active until you change it by selecting another mode.



Using Tap Method

This is the standard mode for entering text on your phone.

Press from any text entry screen and select the **Tap Method** menu option.

Do This	To
1 Press a number key one or more times	select a letter, number, or symbol shown in the "Character Chart" on page 46
2 Continue pressing number keys	enter the remaining characters
3 Press OK ()	store the text when you are finished




General Text Entry Rules

Press a number key repeatedly to cycle through its characters. See "Character Chart" on page 46.

Press a number key as many times as necessary to enter the desired character at flashing cursor location.

Press and hold a number key to cycle between text entry modes.



Change letter in block cursor to uppercase or lowercase.

Move flashing cursor to the left or right in text message.

- If you do not press a key for two seconds, the character in the block cursor is accepted, and the cursor moves to the next position.
- The first character of every sentence is capitalized. (Press  down to force the character to lowercase while it is highlighted by the block cursor).



- Your phone may support multiple languages. The current language setting determines whether a new message begins on the left or right side of the display.

You can switch languages within a message.

Press **MENU** to select the text mode and language you want to use.

Character Chart

Use this chart as a guide for entering spaces, letters, numbers, and symbols with the tap method.

1	space . 1 ? ! , @ _ & ~ : ; " - () ' ï ï % £ \$ ¥ ☰ €
2	a b c 2 á à â ã ç
3	d e f 3 é è ê ë
4	g h i 4 í î ï
5	j k l 5
6	m n o 6 ñ ó ô õ
7	p q r s 7
8	t u v 8 ð ü ú ù û
9	w x y z 9
0	+ - 0 x * / \ [] = > < # §

Note: This chart may not reflect the exact character set available on your phone.



Using Symbol Mode

Your phone provides an alternate way to enter symbol characters in a message. Press  from any text entry screen and select the **Symbol** menu option.

Do This	To
1 Press a number key one time	display its symbol options at the bottom of the display See "Symbol Chart" on page 47.
2 Press  or 	highlight the symbol you want or Press the number key multiple times
3 Press SELECT ()	enter the symbol at the flashing cursor location

Symbol Chart

Use this chart as a guide for entering characters in symbol mode.

	space . ? ! , @ _ & ~ : ; " - () ' i i % £ \$ ¥ ☺ €
	@ _ \ α β
	/ : ; δ φ
	" & ' γ



	() [] { } λ
	č i ~ ω
	< > = π β σ
	\$ £ ¥ ☰ € θ
	# % * ξ ψ
	+ - x * / = > < # §

Using iTAP™ Software Predictive Text Entry Method

iTAP™ software provides a predictive text entry method that lets you enter a word using one keypress per letter.

Press from any text entry screen and select the iTAP menu option.


Enter Words

Do This	To
1 Press a number key one time	enter the first letter of the word The letters associated with the key are shown at the bottom of the display.
2 Press number keys (one per letter)	enter the rest of the word Alternative words and letter combinations are shown at the bottom of the display. The word choices are updated with each keypress.



Do This	To
3 Press or	highlight the word you want
4 Press SELECT ()	enter the word at the flashing cursor location
	A space is automatically inserted after the word.

For example, to spell the word “act,” press . The display shows:



Enter Novel Words

You may enter a word that the iTAP software does not recognize. If the word you want is not displayed:

Do This	To
1 Press DELETE () one or more times	delete letters until you see a letter combination that matches the start of the word



Do This	To
2 Press or	highlight the letter or letter combination
3 Press SELECT () then press	shift the text entry cursor to the left and “lock” the selected word portion
4 Continue to enter letters and highlight letter combinations	spell the word

Punctuation

Press	To
or	enter punctuation or other characters as shown in the “Character Chart” on page 46

Capitalization

The first word of a sentence is automatically capitalized, with following words in lowercase.

Press	To
	change the words to initial character capitalized, all uppercase characters, or all lowercase characters



Enter Numbers

Do This	To
1 Enter the first digit and then highlight it	put the iTAP software in number entry mode
2 Press number keys	add digits to the number
3 Press SELECT (○)	enter the number at the flashing cursor location

Delete Letters and Words

Place the cursor to the right of the text you want to delete, and then do the following:

Do This	To
Press DELETE (○)	delete one letter at a time
Hold DELETE (○)	delete the entire message

Menu Feature Descriptions

This chapter describes all of your phone's features in order of the menu map shown on pages 3–4.

Main Menu

RECENT CALLS

Received Calls

(> Recent Calls
 > Received Calls

View a list of recently received calls. See page 62.

Dialed Calls

(> Recent Calls
 > Dialed Calls

View a list of recently dialed calls. See page 62.

Notepad

(> Recent Calls
 > Notepad

Call or store the last number entered on the keypad.
See page 64.

Call Times

(> Recent Calls
 > Call Times

View call timers that track time spent on
your last call, dialed calls, received calls,
all calls since reset, and all calls total. See page 65.



PHONEBOOK

(> Phonebook

Store names and numbers as entries in your
phonebook, then call numbers by selecting them
from the phonebook list. See page 67.

DATEBOOK

(> Datebook

Use the datebook calendar to schedule and review your appointments. See page 79.

RADIO

(> Radio

Listen to FM radio stations with the optional Motorola Original™ FM Stereo Radio Headset accessory. This menu feature is displayed only when the FM Stereo Radio Headset is plugged into the accessory connector port on your phone. See page 84.



MESSAGES

(> Messages

Adjust message settings, view and manage the various types of messages your phone can send and/or receive:



Create Message Create new text messages. See page 94.

VoiceMail Listen to your recorded voice messages. See page 87.

Text Msgs Read and manage text messages. See page 89.

Quick Notes Select and send pre-written messages from the quick notes list. See page 97.

Outbox View all outgoing text messages, delivered and undelivered.



**Drafts**

Store and edit text messages that you have written but not sent.

RING STYLES**Style**

(**MENU**) > Ring Styles
> Style

Select the ring style your phone uses to notify you of incoming calls, messages, or other events.
See page 99.

Style Detail

(**MENU**) > Ring Styles
> Style Detail

Change details about the current ring style. *Style* represents the name of the ring style. See page 99.

My Tones

(**MENU**) > Ring Styles
> My Tones

Create custom alert tones for your phone. See page 101.

SHORTCUTS

(**MENU**) > Shortcuts

Create keypad or voice shortcuts to menu features.
See page 109.

VOICE NOTES

(**MENU**) > Voice Notes

Use the voice key to record messages and phone calls. See page 113.

Note: Recording phone calls is subject to varying state and federal laws regarding privacy and recording of conversations.

CALCULATOR

(> Calculator

Use your phone as a calculator or currency converter. See page 119.

GAMES

(> Games

Play games on your phone. See page 122.

Settings Menu

PHONE STATUS

My Tel. Number

(> Settings
> Phone Status
> My Tel. Number

View, enter, and edit information about your name and phone number.

Active Line

(> Settings
> Phone Status
> Active Line

Change the active phone line to send and receive calls from either of the available numbers.

Battery Meter

(> Settings
> Phone Status
> Battery Meter

View a detailed battery charge meter.



IN-CALL SETUP

Set the features that are active during a call, such as the in-call timer and call answering options.

**In-Call Timer**

(> Settings
> In-Call Setup
> In-Call Timer

Adjust call timer **Display** and **Beep** settings. You can set your timer to beep at a selected interval during your calls. (60 seconds is the default.) You can also turn on or off a display timer during calls as follows:

Time

Display the elapsed time for the current call.

Off

No in-call timer display.

Answer Options

(> Settings
> In-Call Setup
> Answer Options

Turn call answering options on or off:

Multi-Key Answer by pressing any key.

Open to Answer Answer by opening the flip.

SECURITY**Phone Lock**

(> Settings > Security
> Phone Lock

Lock and unlock your phone. See page 141.

Lock Application

(> Settings > Security
> Lock Application

Lock and unlock specific phone applications (such as phonebook or datebook). When an application is locked, users must enter the unlock code to use the application.

Talk Secure  > Settings > Security
 > Talk Secure

Activate a secure connection to prevent others from intercepting your calls. See pages 31 and 143.

Restrict Calls  > Settings > Security
 > Restrict Calls

Restrict incoming and outgoing calls. See page 142.

New Passwords  > Settings > Security
 > New Passwords

Change your unlock code (originally set to 1234) or your security code (originally set to 000000). See page 139.

OTHER SETTINGS

Personalize  > Settings
 > Other Settings
 > Personalize

Set several personal phone options:

Main Menu Change the order of the main menu. See page 127.

Keys Change the functions of the soft keys and smart key in the idle display. See page 127.





Initial Setup

> Settings
 > Other Settings
 > Initial Setup

Set many basic phone options:

Time and Date	Set the phone's time and date.
Backlight	Set the amount of time that the display backlight remains on, or turn off the backlight to conserve battery power.
Status Light	Turn the status light off (to conserve battery power) and on.
Zoom	Switch between three lines (Zoom Out) and two lines (Zoom In) of display text.
TTY Setup	Set your phone to operate in one of three TTY modes, or return to normal Voice mode. See page 128. 
Scroll	Force the cursor to stop or wrap around when it reaches the top or bottom of a list in the display.



Menu Feature Descriptions

Animation	Turn animation off (to conserve battery power) or on. Animation makes your phone's menus move smoothly as you scroll up and down.
Language	Set the language for phone menus.
Contrast	Adjust the contrast setting for your display.
DTMF	You can send a number to the network as dual tone multi-frequency (DTMF) tones during a call. DTMF tones are used to communicate with automated systems that require you to submit a PIN code or credit card number. Use this option to set DTMF tones to be long, short, or off.
Master Reset	Reset all options back to their original factory settings <i>except</i> for the unlock code, security code, and lifetime timer.



Master Clear

Reset all options back to their original factory settings *except* for the unlock code, security code, and lifetime timer, *and* clear all user settings and entries.

Note: This option *erases all user-entered information* stored in your phone's memory, including phonebook and datebook entries. Once you erase the information, it cannot be recovered.

Network

 > Settings
 > Other Settings
 > Network



View and adjust your phone's network settings.

Your service provider registers your phone to a network. You can view information about the current network, change how your phone searches for a network, and activate alerts that indicate when a call is dropped or network registration changes.

Car Settings

 > Settings
 > Other Settings
 > Car Settings



Adjust hands-free car kit settings.

You can set your phone to route calls directly to the car kit when it detects a connection, and

automatically answer calls after two rings. See page 130.

Note: The use of wireless devices and their accessories may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products.

Headset



- > Settings
- > Other Settings
- > Headset



Set your phone to automatically answer calls after two rings when connected to a headset. See page 130.



Recent Calls

Viewing Received Calls or Dialed Calls

Your phone keeps a list of the calls you recently received and dialed, even if the calls did not connect. The lists are sorted from newest to oldest entries. The oldest entries are deleted as new ones are added.

Shortcut: Press  to go directly to the dialed calls list from the idle display.

Find the Feature

 > Recent Calls

Press	To
1 	scroll to Received Calls or Dialed Calls
2 SELECT ()	select the list
3 	scroll to an entry

Note: ✓ means the call connected.

Press	To
4	call the entry's number
or	
VIEW (O)	
or	view entry details
(MENU)	open the Last Calls Menu to perform other procedures as described in the following list

The Last Calls Menu can include the following options:

Option	Description
Store	Create a phonebook entry with the number in the No. field.
Delete	Delete the entry.
Delete All	Delete all entries in the list.
Send Message	Open a new text message with the number in the To field.
Add Digits	Add digits after the number.
Attach Number	Attach a number from the phonebook or recent call lists, after the highlighted number.

Option	Description
Send Tones	<p>Send the number to the network as DTMF tones.</p> <p>Note: This option appears only during a call.</p>

Using the Notepad

Your phone stores the most recent string of digits entered on the keypad in a temporary memory location called the *notepad*. This can be a phone number that you called, or a number that you entered but did not call. To retrieve the number stored in the notepad:

Find the Feature

( **Recent Calls**
 > **Notepad**)

Press

()

To

call the number

or

()

open the **Dialing Menu** to attach a number or insert a special character

or

STORE ()

create a phonebook entry with the number in the **No.** field

Viewing and Resetting Call Timers

Network connection time is the elapsed time from the moment you connect to your service provider's network to the moment you end the call by pressing **END**. This time includes busy signals and ringing.

The amount of network connection time you track on your resettable timer may not equal the amount of time for which you are billed by your service provider. For billing information, please contact your service provider directly.



You can view the following network connection times:

Timer	Description
Last Call	Approximate time spent on last dialed or received call. You cannot reset this timer.
Dialed Calls	Approximate time spent on dialed calls since the last time you reset this timer.
Received Calls	Approximate time spent on received calls since the last time you reset this timer.
All Calls	Approximate time spent on dialed and received calls since the last time you reset this timer.

Timer	Description
Lifetime	Approximate time spent on all calls on this phone. You cannot reset this timer.

To view a call timer:

Find the Feature



> Recent Calls
> Call Times

Press	To
1	scroll to the timer you want
2 SELECT (view the recorded time

To reset the call timer:

Press	To
1 RESET (reset the time (if available)
2 YES (confirm the reset

Phonebook

You can store a list of names and phone numbers or email addresses in your phone's electronic phonebook.

To see the names in your phonebook, press **MENU > Phonebook** from the idle display. Scroll to a name and press **VIEW (O)** to view details of the phonebook entry as shown below.

Shortcut: Press **(O) down** from the idle display to open the phonebook.

Viewing Entry Details

Type indicator identifies number type:

-  Work
-  Home
-  Main
-  Mobile
-  Fax
-  Pager
-  Email

Voice Name indicator indicates a recorded voice name

Carlo Emrys—
2154337215
Speed No.15

Entry's Name

Entry's phone number or email address

Entry's speed dial number

Return to list

Press **MENU** to open the Phonebook Menu

Edit entry



Note: When you set a distinctive ringer alert for an entry, the **Ringer ID** setting appears below the speed dial number.

Creating a Phonebook Entry

A phone number or email address is required for a phonebook entry. All other information is optional.

Shortcut: Press up from the idle display to open the phonebook and go to [New Entry].

Shortcut: Enter a phone number in the idle display, then press **STORE** () to create a phonebook entry with the number in the **No.** field. Go directly to step 3 to continue.

Enter Information

Find the Feature

> Phonebook
 > New

Press	To
1	scroll to Phone Number or Email Address
2 SELECT ()	select the entry type
3 CHANGE ()	select Name
4 keypad keys	enter a name for the entry
5 OK ()	store the name
6 CHANGE ()	select No. or Email
7 keypad keys	enter the phone number or email address (to a maximum of 32 characters)

Tip: You can store a PIN code with the phone number. See page 70.



Press	To
8 OK (○)	store the phone number or email address
9 CHANGE (○)	select Type Note: This option is not available for email entries.
10 (○)	scroll to the number type
11 SELECT (○)	select the number type
12 RECORD (○) or	record a voice name for the entry, if desired Go to step 13 if you do not want a voice name
13 (○)	scroll to Speed No. The next available speed dial number is assigned to a new phonebook entry.
14 CHANGE (○)	select Speed No. if you want to change it
15 keypad keys	enter a different speed dial number, if desired
16 OK (○)	store the speed dial number



Press	To
17 CHANGE (○)	select Ringer ID if you want to assign a distinctive ringer alert for the phone number Your phone uses the alert to notify you when you receive a call from this phone number. See page 100.
18 (○)	scroll to the alert you want
19 SELECT (○)	store the ringer ID alert
20 SELECT (○)	select MORE if you want to create another entry under the same Name You must use a different Type identifier for each number.

Complete Phonebook Entry

When you are finished entering information for a phonebook entry:

Press	To
DONE (○)	store the entry

Storing a PIN Code With a Phone Number

You can store a PIN code with the phone number for calls that require additional digits (for example, to make a calling card call, or to retrieve voicemail or answering machine

messages). Insert one or more of the following characters in the dialing sequence to ensure that the number dials and connects properly:

Press	To
 > Insert Pause	insert a p (pause) character Your phone dials the preceding digits, waits for the call to connect, then sends the remaining digit(s).
 > Insert Wait	insert a w (wait) character Your phone dials the preceding digits, waits for the call to connect, then prompts you for confirmation before it sends the remaining digit(s).
 > Insert 'n'	insert an n (number) character Your phone prompts you for a number before dialing the call. The number you enter is inserted into the dialing sequence in place of the n character

Note: You can store a maximum of 32 digits per number. Each character counts as one digit.



Recording a Voice Name For a Phonebook Entry

You can record a voice name for a new or existing phonebook entry. A voice name lets you call the phonebook entry using voice dial (see page 73).

Tip: Make your recording in a quiet location. Hold the phone about four inches (10 centimeters) from your mouth, and speak directly into the phone in a normal tone of voice.

Find the Feature



Phonebook

Do This	To
1 Press	scroll to the entry
2 Press VIEW ()	view entry details
3 Press EDIT ()	edit the entry
4 Press	scroll to Voice Name
5 Press RECORD ()	begin recording
6 Press and release the voice key and say the entry's name (in two seconds)	record the voice name
7 Press and release the voice key and repeat the name	confirm the voice name
8 Press DONE ()	store the voice name



Dialing a Phonebook Entry

Use one of the following procedures to call a number (or send a text message to an email address) stored in your phonebook.

Phonebook List

Find the Feature

 > Phonebook

Press	To
1 keypad key letter	jump to entries that begin with that letter (optional)
2 	scroll to the entry
3 	make the call

Voice Dial

Do This	To
Press and release the voice key and say the entry's name (in two seconds).	make the call

To speed dial a phonebook entry, see page 34. To call an entry with one-touch dial, see page 34.





Storing Longer Numbers

A phonebook number can contain a maximum of 32 digits and characters. You can create multiple phonebook entries to store a dialing sequence that exceeds the 32-character limit. Then you can send the entries in sequence to dial the number.

To store a dialing sequence longer than 32 characters:

Do This

- 1 Create a phonebook entry to store the first part of the dialing sequence (for example, the number for your long-distance service provider).
- 2 Create a second phonebook entry to store the next part of the dialing sequence (for example, the country code and phone number for an international call).
- 3 Repeat step 2 as necessary to store the entire dialing sequence. (For example, create a third phonebook entry to store your calling card number and PIN number.)

To dial a dialing sequence stored as multiple phonebook entries:

Do This

- 1 Dial the first phonebook entry. Perform any pause or wait tasks, if necessary, to complete the dialing sequence. Your phone returns to the idle display.

Do This

- 2 Press  > Phonebook to re-open the phonebook.
- 3 Highlight the second phonebook entry, then press  > Send Tones to send the next portion of the dialing sequence.
- 4 Repeat steps 2 and 3 as necessary to send the entire dialing sequence.

Editing a Phonebook Entry

Find the Feature

 > Phonebook

Press	To
1 	scroll to the entry
2 VIEW ()	view entry details
3 EDIT ()	edit the entry

Edit the entry as described on pages 68-70.

Deleting a Phonebook Entry

Find the Feature

 > Phonebook

Press	To
1 	scroll to the entry
2 	open the Phonebook Menu
3 	scroll to Delete
4 SELECT ()	select Delete
5 YES ()	confirm the deletion



Setting the Primary Number for a Phonebook Entry

When you enter multiple phone numbers for the same name, you can set one as the primary number.

Find the Feature



Phonebook

Press	To
1	scroll to the entry
2	open the Phonebook Menu
3	scroll to Set Primary
4 SELECT (select Set Primary
5	scroll to the number you want to set as the primary number
6 SELECT (set the primary number

Depending on how the phonebook list is sorted, the primary number is listed first, or is the only number that appears for a phonebook entry. See page 77.

Checking Phonebook Capacity

You can see how much memory space remains for storing phonebook and datebook entries on your phone.

Find the Feature



Phonebook

Press	To
1	open the Phonebook Menu



Press	To
2 	scroll to Ph Book Capacity
3 SELECT 	select Ph Book Capacity Your phone displays the phone memory meter.

Sorting the Phonebook List

You can sort your phonebook list by speed dial number (the standard), name, email address, or voice name.

Note: The voice name sort is identical to the name sort, except that entries with voice name tags appear first.

Find the Feature

 > Phonebook

Press	To
1 	open the Phonebook Menu
2 	scroll to Setup
3 SELECT 	select Setup
4 	scroll to Sort by
5 CHANGE 	select Sort by
6 	scroll to Name, Speed No., Voice Name, or Email
7 SELECT 	select the sort order

If you select Speed No., Voice Name, or Email, the procedure is complete.



If you select **Name**, you must specify whether you want to view all numbers or just the primary number for each name:

Press	To
8 CHANGE (○)	change view preference
9 (○)	scroll to Primary Contacts or All Contacts
10 SELECT (○)	select the view preference
11 DONE (○)	set the view preference

To set an entry's primary phone number, see page 76.

Tip: When the phonebook list displays primary numbers only, you can scroll to a name and press (•*) or (#) to view other numbers associated with the name.

Synchronizing with TrueSync Software



You can synchronize phonebook entries between your phone and computer or hand-held device with Starfish TrueSync® software, a Motorola accessory product. See the TrueSync user guide for more information.

Note: TrueSync software is designed to synchronize with basic features of many popular Personal Information Management (PIM) software and hardware products.

Datebook

The *datebook* is a calendar that lets you schedule and organize events such as appointments and meetings. You can set the datebook to send a reminder alarm for specific events.

Note: You must set the correct time and date on your phone to use the datebook.


To schedule or review datebook events:

Find the Feature

(**MENU**) > Datebook


Week View

The datebook initially displays a calendar for the week. Lines or filled boxes indicate scheduled events.




Day View

Select a day and press **VIEW** (⌚) to see the day's events.



Event View

Select an event and press **VIEW** (⌚) to see event details.



Adding a Datebook Event

A title is required for a datebook event. All other information is optional.

Note: You must create an event to use the reminder alarm.

Find the Feature

( > Datebook > day
( > New

Press	To
1 CHANGE ()	select Title
2 keypad keys	enter a title for the event
3 OK ()	store the event title
4 	scroll to other fields and enter information as necessary You can set start time, duration, date, repeat interval, and reminder alarm.
5 DONE ()	store the event

Changing Event Information

Find the Feature

( > Datebook

Press	To
1  or 	scroll to the day
2 VIEW ()	display the day view
3 	scroll to the event
4 VIEW ()	display the event view
5 EDIT ()	edit the event





Press	To
6	scroll to the information you want to change
7 CHANGE (edit the information
8 keypad keys	enter new information
9 DONE (<td>store the information</td>	store the information

Copying an Event

Find the Feature

> Datebook

Press	To
1 or	scroll to the day
2 VIEW ()	display the day view
3	scroll to the event
4	open the Datebook Menu
5	scroll to Copy
6 SELECT ()	copy the event
7 YES ()	confirm the copy
	Your phone assumes you want to change the date, and displays the Date field.
8 keypad keys	enter date information
9 ► ()	move to month, day, and year
10 DONE ()	save the copy of the event
11	scroll to and edit event information, if necessary
12 DONE ()	store the information

Deleting an Event

Find the Feature



> Datebook

Press	To
1 or	scroll to the day
2 V IEW ()	display the day view
3	scroll to the event
4	open the Datebook Menu
5	scroll to Delete
6 S ELECT ()	select Delete
7 Y ES ()	confirm the deletion

Synchronizing with TrueSync Software



You can synchronize datebook entries between your phone and computer or hand-held device with Starfish TrueSync® software, a Motorola accessory product. See the TrueSync user guide for more information.

Note: TrueSync software is designed to synchronize with basic features of many popular Personal Information Management (PIM) software and hardware products.



Radio



You can use your phone to listen to FM radio stations when the optional Motorola Original™ FM Stereo Radio Headset accessory is plugged into the phone's accessory connector port.

Turning the Radio On and Off

Press	To
Radio (○)	turn the radio on and off

Alternatively, you can use the following procedure:

Find the Feature > Radio

Press	To
On (○) or Off (○)	turn the radio on or off

Note: The Radio menu feature and soft key options appear only when the FM Stereo Radio Headset is plugged into the accessory connector port.

Tuning a Station

Do This	To
Press 	scroll to the next frequency
or	
Press and hold 	scroll to the next available stereo station



Radio

Storing a Preset

Do This	To
Press and hold a number key  to 	assign its preset number to the tuned station

Selecting a Preset

Press	To
a number key  to 	tune the station stored at the preset location

Sending and Receiving Calls With the Radio On

Your phone rings or vibrates as usual to notify you of an incoming call, message, or other event.



Do This	To
Press IGNORE (○)	ignore the call
Press ANSWER (○) or Press the button on the FM Stereo Radio Headset microphone	Note: You can use the FM Stereo Radio Headset microphone to converse with the other party during a call

To end the call and resume the FM broadcast:

Do This	To
Press END	end the call
or Press and hold the button on the FM Stereo Radio Headset microphone	

Turn the radio off before dialing outgoing calls from the phone keypad. You do not have to turn off the radio to dial emergency numbers, or numbers selected from your phonebook or recent call lists.

Tip: To dial a recently called number, press **(SND)** or the button on the FM Stereo Radio Headset microphone to go to the dialed calls list. For more information, see page 62.

Messages—Voicemail



You can listen to your voicemail messages by calling your network voicemail phone number. Voicemail messages are stored on the network—not on your phone.

Storing Your Voicemail Number



Storing your voicemail number on your phone makes it easy for you to listen to new voicemail messages. In many cases, your service provider has already done this for you.

Find the Feature

(> Messages
(> VoiceMail Setup

Press	To
1 keypad keys	enter your voicemail number
2 OK (○)	store the number

Your service provider additionally may store your voicemail number as phonebook entry number 1, so you can use one-touch dial to listen to your voicemail messages. If necessary, see page 68 to store your voicemail number for one-touch dial access.

Receiving a Voicemail Message

When you receive a voicemail message, your phone displays the  (voice message waiting) indicator and a New VoiceMail notification.

Press	To
CALL 	listen to the message



If reminders are turned on, your phone sends a reminder at regular intervals until you close the new message notification, listen to the message, or turn off your phone.

Listening to a Voicemail Message

Find the Feature

 > Messages > VoiceMail

The phone calls your voicemail number. If no voicemail number is stored, your phone prompts you to store one.

Shortcut: If your voicemail number is also stored as phonebook entry number 1, you can press and hold  to listen to your voicemail message(s).

Messages—Text



Text messages are brief messages that you can send and receive.

Quick notes are pre-written text messages that you can incorporate into a message and send quickly.

Your text message inbox must be set up *before* you can send and receive messages. The number of messages the inbox can hold depends on the length of the messages, and the number of other messages and drafts stored on your phone.

Setting Up the Text Message Inbox



Note: In many cases, your service provider has already set up the text message inbox for you.

Find the Feature

(> Messages
(> Text Msg Setup

Press	To
1 OK (store the number
2 CHANGE (<td>change the Expire After period</td>	change the Expire After period
3 keypad keys	enter the expiration period—the number of days your network tries to send undelivered messages



Press	To
4 OK (○)	store the expiration period
5 CHANGE (○)	change the Cleanup setting
6 (○)	scroll to the number of days you want to keep messages in the inbox, or the number of messages you want to keep
7 SELECT (○)	select the cleanup setting
8 CHANGE (○)	change the SMS Alert setting
9 (○)	select whether you want incoming message alerts turned On or Off while you are on a voice call
10 SELECT (○)	select the SMS Alert setting
11 DONE (○)	save the inbox settings

Receiving a Text Message

Note: Your text message inbox must be set up before you can receive text messages. See page 89.

When you receive a text message, your phone displays the (message waiting) indicator and a **New Message** notification, and gives an alert.

Press	To
READ (○)	open the message

If reminders are turned on, your phone sends a reminder at regular intervals until you close the new message notification, read the message, or turn off your phone.

As memory space for storing messages gets close to full, the  (message waiting) indicator flashes and your phone displays **Memory is Low!** when you receive a new message. When memory is full, your phone automatically deletes the oldest read and unlocked messages to make space for an incoming message. If memory is filled with unread and/or locked messages, your phone displays **Memory is Full!**, and the network temporarily holds new messages until you manually delete some existing messages.

Reading, Locking, or Deleting a Text Message

Messages in the text message inbox are sorted from newest to oldest. The oldest messages are deleted automatically as specified by the inbox cleanup setting (see page 89). If you want to save a message, you should lock it to prevent it from being deleted during cleanup.



Find the Feature



> **Messages> Text Msgs**

Press	To
1 	scroll to the message

The following indicators show message status:

**Press****To**

- ✉ = unread
- ✉ = unread (with attachment)
- ✉! = unread and urgent
- ✉! = unread and urgent
(with attachment)
- ✉ = read
- ✉ = read (with attachment)
- ✉ = read and locked
- ✉ = read and locked
(with attachment)

2 READ (○)

open the message

3 BACK (○)

close the message

or

REPLY (○)

compose and send a reply

or

open the **Text Msg Menu** to
perform other procedures as
described in the following list

The **Text Msg Menu** can include the following options:

Option	Description
Delete	Delete the message.
Call Back	Call the number in the message header or embedded in the message.

Option	Description
Forward	<p>Open a copy of the text message, with an empty To field.</p> <p>Note: You cannot forward sound files embedded in a text message. Only the text is forwarded.</p>
Store Tone	Store the selected sound file.
Play	Play a sound file in the message.
Lock/Unlock	Lock or unlock the message.
Store Number	Create a phonebook entry, with the embedded number in the No. field.
Delete All	Delete all inbox messages.
Create Message	Open a new text message.
Store Address	Create a phonebook entry, with the embedded email address in the Email field.
Setup	Open the text message inbox setup menu.

Storing Sounds

You can receive a text message that contains a ring tone or other sound. The ring tone plays when you open the message.



You can store the ring tone on your phone, and use it as an event alert.

Press	To
1 	open the Text Msg Menu
2 	scroll to Store Tone
3 SELECT ()	select the option Your phone adds the tone to the My Tones list.

For more information about using ring tones, see pages 99 and 101.

Sending a Text Message



You can send a text message to one or more recipients. You can manually enter each recipient's phone number or email address, or select numbers/addresses from the phonebook or recent call lists.

Note: When you manually enter numbers and/or email addresses, you must insert a space between each entry. Press and hold  until the space appears, then enter the next number or email address.

Find the Feature

 > Messages
> Create Message

Press	To
1 CHANGE ()	select To

Press	To
2 keypad keys	enter one or more phone numbers and/or email addresses
	Tip: Press  to insert a space between each number/address that you enter manually.
or	
BROWSE ()	select numbers/addresses from the phonebook or recent call lists
a 	
b SELECT ()	
c 	
d ADD ()	
e DONE ()	
3 OK ()	store the numbers/addresses
4 CHANGE ()	select Msg





Press	To
5 keypad keys	enter the message
Note: Message length is limited. When you have 40 characters left, a display counter shows how many characters you can still enter.	
or	
6 BROWSE (○)	select and insert a quick note message (see page 97)
7 OK (○)	store the message
7 CHANGE (○)	select Priority
8 (○)	scroll to the priority you want
9 SELECT (○)	set the priority
10 DONE (○)	finish the message
11 YES (○)	send the message
or	
NO (○)	cancel the message or save it in the drafts folder

Sending a Quick Note Text Message

Quick notes are pre-written text messages that you can incorporate into a message and send quickly (for example, Meet me at ...). You can also create new quick notes.

Find the Feature

 > Messages
> Quick Notes

Press	To
1 	scroll to the quick note
2 READ ( <td>read the quick note</td>	read the quick note
or	
	open the Quick Note Menu to perform other procedures as described in the following list

The Quick Note Menu can include the following options:

Option	Description
New	Create a new quick note.
Edit	Edit the quick note.
Delete	Delete the quick note.
Send	Open a new message with the quick note in the Msg field.



Viewing the Status of Sent Text Messages

Messages that you send are stored in the outbox.

Find the Feature



> **Messages > Outbox**

Messages in the outbox are sorted from newest to oldest.
The following indicators show message status:

» = sending in progress

✉ = sent

✗ = sending failed

✉ = read by recipient

Tip: To re-send an undelivered message, highlight the message and then press > **Re-send**. Your phone gives you the option to edit the destination or message before you re-send it.

Ring Styles

Your phone rings or vibrates to notify you of an incoming call or other event. This ring or vibration is called an *alert*. You can select one of five different ring styles:

 = loud ring

 = soft ring

 = vibrate

 = vibrate and ring

 = silent

The ring style indicator in the display shows the current ring style (see page 24).

Each ring style contains settings for specific event alerts, ringer ID, and ringer and keypad volume.

Selecting a Ring Style

Find the Feature

 > Ring Styles > Style

Press	To
1 	scroll to the ring style
2 SELECT ( <td>select the ring style</td>	select the ring style



Customizing a Ring Style

Change Style Settings

You can change the alerts that notify you of the following events: incoming calls, text messages, voicemail

messages, data calls, fax calls, alarms, and reminders. Any changes you make are saved to the current ring style.

Find the Feature

 > Ring Styles
> Style Detail

Note: *Style* represents the current ring style.

Press	To
1 	scroll to the event
2 CHANGE ()	select the event
3 	scroll to the alert you want
4 SELECT ()	select the alert

Activate and Deactivate Ringer IDs

When ringer IDs are turned on, your phone uses distinctive ringer alerts to notify you of incoming calls or messages from specific entries stored in your phonebook. To assign a ringer ID to a phonebook entry, see page 68.

Find the Feature

 > Ring Styles
> Style Detail

Note: *Style* represents the current ring style.

Press	To
1 	scroll to Ringer IDs
2 CHANGE ()	change the ringer IDs setting
3 	scroll to On or Off
4 SELECT ()	select the option

Set Ringer or Keypad Volume

Find the Feature

(**MENU**) > Ring Styles
> Style Detail

Note: *Style* represents the current ring style.

Press	To
1 (scroll to Ring Volume or Key Volume
2 (*) or (#)	scroll to the desired volume
3 OK (confirm the new volume

Using My Tones

You can create and store custom alert tones on your phone. The tones appear in the list of available alerts.

Create a Tone

Find the Feature

(**MENU**) > Ring Styles
> My Tones

Press	To
1 (scroll to [New Tone]
2 SELECT (select [New Tone]
3 CHANGE (select Notes
4 keypad keys	enter notes (see following section)
5 OK (store the notes
6 CHANGE (select Name
7 keypad keys	enter a name for the tone



Press	To
8 OK (○)	store the name
9 DONE (○)	store the tone

Enter Notes

To create a new tone, use the keypad keys to enter notes. For each note, you must specify the octave (optional), pitch, length, and a length modifier (optional). Press a key multiple times to cycle through its available options and enter the necessary character as described in the following lists.

Octave

The default setting for a new tone is octave four.

Key	Display	Description
0	*	enter * followed by a number (0 to 8) to set the octave

Notes and Rests

Key	Display	Description
0	#	sharp
	&	flat
2ASC	a	note A
	b	note B
	c	note C



Key	Display	Description
3 DEF	d	note D
	e	note E
	f	note F
4 GHI	g	note G
7 PQRS	r	rest

Lengths and Modifiers

Key	Display	Description
0	0	whole note
1	1	half note
2	2	quarter note
3	3	eighth note
4	4	sixteenth note
5	5	1/32 note
1	.	dotted note
	:	double dotted note
	;	2/3 length note

Note Entry Sequence

Do This	Action
1 Set the octave (optional)	Set the octave (*0 to *8) before selecting the note. The octave applies to the note and all following notes until you change it again.



Do This	Action
2 Set the note to a sharp or flat, if necessary	Enter a sharp or flat (# or &) <i>before</i> selecting the note.
3 Select the note (required)	Press a keypad key.
4 Set length (required)	Set the length (0 to 5) <i>after</i> selecting the note. If you do not specify a length, a 2 (quarter note) length is appended to the note.
5 Modify length (optional)	Enter a length modifier (., :, or ;) <i>after</i> you set the length.

You can perform the following tasks when creating a tone:

Task	Action
Insert a rest	Enter one or more rests (r characters) as needed in the tone sequence. Set the length of the rest (0 to 5) <i>after</i> the rest, just as you would for a note.
Listen to a new tone as you compose it	Press to enter the Compose Menu, and select Play All to play the notes you have entered.



Example

Press the following keys to create this sequence of notes and rests in octave three: **C** (quarter note), **E flat** (quarter note), **half rest**, and **G** (whole note):

Press	To	Display
1 	set octave three	*3
2	enter note C	c
3	set length to quarter note	2
4	enter flat symbol	&
5	enter note E flat	e
6	set length to quarter note	2
7	enter rest	r
8	set length to half rest	1
9	enter note G	g
10	set length to whole note	0

Play a Tone

Find the Feature

> Ring Styles
> My Tones

Press	To
1	scroll to the tone
2	open the My Tones Menu
3	scroll to Play
4 SELECT (select Play
5 PLAY (<td>play the tone again</td>	play the tone again
or	
CANCEL (<td>return to my tones list</td>	return to my tones list

Edit a Tone

You cannot edit the predefined alert tones included with your phone. To edit a custom alert tone:

Find the Feature

> Ring Styles
 > My Tones

Press	To
1	scroll to the tone
2 EDIT (<td>open the tone details</td>	open the tone details
3	scroll to the item you want to edit (Name or Notes)
4 CHANGE (<td>select the item</td>	select the item
5 keypad keys	enter new text or notes
6 OK (<td>store the new text or notes</td>	store the new text or notes
7 DONE (<td>save your changes</td>	save your changes

Delete a Tone

You cannot delete the predefined alert tones included with your phone. To delete a custom alert tone:

Find the Feature

(**MENU**) > Ring Styles
> My Tones

Press	To
1 (○)	scroll to the tone
2 (MENU)	open the My Tones Menu
3 (○)	scroll to Delete
4 SELECT (○)	select Delete
5 YES (○)	confirm the deletion

Download a Tone

You can download custom alert tones from a text message. See page 93.

Setting Reminders

A reminder is an alert that rings or vibrates at regular intervals to notify you about a voicemail or text message that you have received.

Find the Feature

(**MENU**) > Ring Styles
> Style Detail
> Reminders



Note: *Style* represents the current ring style.

Press	To
1 	scroll to Beep or Vibrate to set the reminder alert type, or Off to turn off all reminders
2 SELECT ()	select the reminder alert

Ring Styles



Shortcuts

Your phone includes several standard shortcuts. You can create additional shortcuts to frequently used menu items.

Standard Shortcuts

The following shortcuts are pre-programmed in your phone. You cannot edit or delete these shortcuts.

Do This	To
Press (MENU) , then press and hold (MENU) (within two seconds)	zoom in/out on your phone display
Press the down volume key (at lowest volume setting)	switch to vibrate alert, then silent alert Press the up volume key to cycle back to vibrate alert, then ring alert.
Press (MENU) #	see your phone number
Press (SND) (SND)	go to the dialed calls list
Press (END) (END)	exit the menu system
Press (down	open the phonebook
Press (up	open the phonebook and go to [New Entry]



Creating a Shortcut

You can create a keypad shortcut *plus* an optional voice shortcut to a menu item. A voice shortcut takes you directly to the menu item when you say the shortcut name.

Tip: Make your recording in a quiet location. Hold the phone about four inches (10 centimeters) from your mouth, and speak directly into the phone in a normal tone of voice.

Do This	To
1 Press 	enter the menu system
2 Press 	scroll to the menu item
3 Press and hold 	open the shortcut editor
4 Press YES ()	view shortcut options
5 Press CHANGE ()	change the keypad shortcut number
or	
Press DONE ()	select the default keypad shortcut number
or	
Press 	scroll to Voice to assign a voice shortcut



Do This	To
6 Press CHANGE (○)	change the keypad shortcut number
or	
Press DONE (○)	select the default keypad shortcut number
or	
Press (○)	scroll to Voice to assign a voice shortcut
7 Press RECORD (○) RECORD (○)	begin recording
8 Press and release the voice key and say the shortcut's name (in two seconds)	record the shortcut name
9 Press and release the voice key and repeat the name	confirm the shortcut name
10 Press DONE (○) DONE (○)	store the shortcut name

Using Shortcuts

Use a Keypad Shortcut

Press	To
1 (MENU)	open the main menu



Press	To
2 a number key	go to the menu item with that shortcut number

Select a Shortcut From the List

Find the Feature



> Shortcuts

> *shortcut name*

Use a Voice Shortcut

Do This	To
1 Press	open the menu
2 Press and release the voice key and say the shortcut's name (in two seconds)	go to the menu item with that shortcut name



Voice Notes

You can use the voice note feature to record personal messages and phone calls on your phone.



Voice Notes

Recording a Voice Note

Use this procedure to record a voice note from the idle display, or to record a phone call in progress. Your phone plays an alert tone to notify the other party that the call is being recorded.

Note: Recording phone calls is subject to varying state and federal laws regarding privacy and recording of conversations.

Tip: Make your recording in a quiet location. Hold the phone about four inches (10 centimeters) from your mouth, and speak directly into the phone in a normal tone of voice.


Do This	Result
1 Press and hold the voice key for the duration of the recording.	The phone sounds an alert tone and begins recording.
2 Speak your voice note.	The phone records the voice note.
3 Release the voice key to stop recording.	The phone displays the voice note number and total recording time.

Viewing the Voice Notes List

Find the Feature



> Voice Notes



Playing a Voice Note

Find the Feature



> Voice Notes


Press	To
1	scroll to the voice note
2 PLAY ()	play the voice note

When you connect an optional Motorola Original™ headset or FM Stereo Radio Headset accessory to your phone, playback is automatically routed to the headset.

Tip: You can play a voice note while taking a call. It will not be transmitted to the other party.


Playback Screen

The playback screen is displayed as the voice note plays.





Voice Note Controls



Locking and Unlocking a Voice Note

Lock a voice note to prevent it from being deleted. You must unlock a voice note to delete it.

Find the Feature

(**MENU**) > Voice Notes

Press	To
1 (○)	scroll to the voice note
2 (MENU)	open the Voice Notes Menu
3 (○)	scroll to Lock or Unlock
4 SELECT (○)	lock or unlock the voice note

To lock or unlock a voice note during playback:

Press	To
1 (MENU)	open the Voice Notes Menu
2 (○)	scroll to Lock or Unlock
3 SELECT (○)	lock or unlock the voice note

Playback stops when you lock or unlock a voice note.
Press any number key to resume playback.



Voice Notes

Deleting a Voice Note

Find the Feature



> **Voice Notes**

Press	To
1	scroll to the voice note
2	open the Voice Notes Menu
3	scroll to Delete or Delete All
4 SELECT (select the highlighted option
5 YES (<td>confirm the deletion</td>	confirm the deletion
or	
NO (<td>cancel deletion</td>	cancel deletion

Notes:

- You cannot delete a locked voice note.
- You cannot recover a deleted voice note.

Calculator


You can use your phone as a calculator and currency converter.

Calculating Numbers

Find the Feature

 > Calculator

Press	To
1 number keys	enter a number
2  or 	highlight a calculator function
3 SELECT ()	perform the function



Calculator





The calculator can perform the following functions:

Function	Description
.	Insert a decimal point
C	Clear the calculation
CE	Clear entry (replaces C when you enter subsequent values in a calculation)
=	Calculate the result
+	Add
-	Subtract
X	Multiply
÷	Divide
%	Divide the displayed value by 100
±	Change the entry's sign (positive/negative)
\$	Calculate the exchange rate
MS	Store the value in memory (overwrites current stored value)
MC	Clear the value stored in memory
MR	Replace the displayed value with the value stored in memory

Converting Currency

The currency converter works just like the calculator, but uses the \$ (currency) function:

Find the Feature

(> Calculator
(> Exchange Rate

Press	To
1 number keys	enter the exchange rate
2 OK (store the exchange rate
3 number keys	enter the amount to convert (amount to multiply by the exchange rate)
4 or	highlight the \$ function
5 SELECT (perform the conversion



Calculator

Games

You can play games on your phone between phone calls. An incoming call, message, alarm, or alert automatically ends the game.

Playing a Game

Find the Feature

 > Games

Press	To
1 	scroll to a game
2 SELECT 	start the game

When the game is over:

Press	To
NEW  or YES 	start another session of the same game
BACK  or NO 	end the game session

Blackjack

In this classic card game, you play against the dealer to see who can get closer to 21 points without going over.

Rules of the Game

- The first card is dealt to the dealer. The dealer's cards are shown at the top of the display, and your cards are shown at the bottom.
- Face cards count as 10 points. Number cards count as the points shown on their face.
- An ace counts as 11 points, unless that would put you over 21 points. Otherwise, an ace is counted as 1 point. An ace that is originally counted as 11 may later be counted as 1 if it will bring your total under or equal to 21 points.
- An initial deal of an ace and a card with a face value of 10 points counts as exactly 21 points or Blackjack.
- Blackjack automatically wins against any other hand that totals 21 points.
- If you score more than 21 points, you go “bust” or lose.
- If you get five cards without going bust, you win.
- If you and the dealer have the same score, the dealer wins.
- You can ask for a “hit” or another card as long as you do not go bust.
- As long as the dealer's total is less than 17 points, the dealer must continue to take a hit.



How to Play

When the game begins, you are dealt two cards.

Press	To
STAY (○)	see the results of the hand
HIT ME (○)	request another card

Falling Numbers

Score points by pressing the corresponding number key for numbers as they “fall” down the display.

Rules of the Game

- If a number reaches the bottom of the display or if you press an incorrect number key, you score one miss.
- The game is over when you score three misses.
- The game has five levels. When you complete a level, play continues automatically at the next level.
- You earn a bonus if you finish a level without a miss.

How to Play

When the game begins, numbers start falling from the upper portion of the display. Press the corresponding number key to eliminate a falling number before it reaches the bottom of the display.

Press  to select the following options:

Option	Description
Game Sounds	Switch game sounds on/off.
New Game	Start a new game.
Level	Choose the starting level of play.
Top Scores	View the top five scores.
Help	Review the goal of the game.

Video Poker

Turn 100 credits into 9,999-plus credits by making the best possible poker hands.

Rules of the Game

- You start a new game with 100 credits. You must bet from 1-10 credits for each hand you play.
- You are dealt five cards face up, and have one opportunity to trade in cards (zero to five) for new ones.
- A winning hand earns credits as listed in the **Awards Table**.
- Your credit total is saved when you exit the game. The next time you play, you start with the number of credits that remain from the previous session.
- The game is over when you lose all of your credits.



How to Play

Place your initial bet or change your bet (from 1-10 credits) and then:

Press	To
NEW (○)	start a new hand
4 CHL or 1*	select the card to the left
6 MHO or #	select the card to the right
5 HSL or DISCARD (○)	discard selected card
5 HSL or UNDO (○)	undo discard (replaces previous option after discard)
DONE (○)	remove discarded cards and deal replacements

Press **MENU** to select the following options:

Option	Description
Change Bet	Change bet amount (not available while hand is in play).
Game Sounds	Switch game sounds on/off.
New Game	Start a new game.
Choose Deck	Change the design that appears on the backs of the cards.
Awards Table	View the list of odds/payouts for each winning hand.
Game Sounds	Switch game sounds on/off.
Level	Choose the starting level of play.
Top Scores	View the top five scores.
Help	Review the goal of the game.

Adjusting Your Settings

Reordering Menu Items

You can reorder the items in your phone's main menu.

Find the Feature

- > Settings
- > Other Settings
- > Personalize
- > Main Menu

Press	To
1 (○)	scroll to a menu item
2 GRAB (○)	grab the menu item
3 (○)	move the item to a new location in the menu
4 INSERT (○)	insert the menu item

Customizing a Soft Key Function



You can relabel the soft keys (○ and ○) and the smart key to access different menu items from the idle display.

Find the Feature

- > Settings
- > Other Settings
- > Personalize > Keys

Press	To
1 	scroll to Left, Right, or Smart
2 CHANGE 	select the key
3 	scroll to the new key function
4 CHANGE 	confirm the new function

TTY Operation



You can use an optional TTY device with your phone to send and receive calls. You must plug the TTY device into the phone's headset jack and set the phone to operate in one of three TTY modes.

For additional information, or if you have questions, contact your cellular service provider or Motorola. Motorola has tested various TTY products manufactured by Ameriphone and Ultratec.

Notes:

- Use a TSB-121 compliant cable (provided by the TTY manufacturer) to connect the TTY device to your phone.
- Set the phone volume to level 4 (middle setting) for proper operation. If you experience a high number of incorrect characters, adjust the volume as necessary to minimize the error rate.
- For optimal performance, your phone should be at least 12 inches (30 centimeters) away from the TTY device. Placing the phone too close to the TTY device may cause high error rates.



Set TTY Mode

When you set your phone to a TTY mode, it operates in that mode whenever the TTY device is connected.

Find the Feature

> Settings
 > Other Settings
 > Initial Setup
 > TTY Setup

Press	To
1	scroll to TTY Setup
2 CHANGE ()	change the TTY mode
3	scroll to the TTY mode
4 SELECT ()	select the TTY mode

The TTY Setup menu can include the following options:

Option	Description
TTY	Transmit and receive TTY characters
VCO	Receive TTY characters but transmit by speaking into the microphone
HCO	Transmit TTY characters but receive by listening to the earpiece
Voice	Return to normal voice mode

- When your phone is in a TTY mode, the international TTY symbol and the mode setting are shown in the display during an active digital TTY call. You can press **TTYMODE** () to change the mode setting.

Switch to TTY Mode During a Voice Call

Press	To
1 	open the Call menu
2 	scroll to TTY Setup
3 SELECT 	display the TTY Setup menu
4 	scroll to the TTY mode
5 SELECT 	select the TTY mode

Return to Voice Mode

To return to normal voice mode, select **Voice** from the TTY Setup menu as described on page 129.

Hands-Free Use



You can purchase an optional Motorola Original™ hands-free car kit or headset for your phone.

These accessories provide alternative ways for you to use your phone without using your hands.

Note: The use of wireless devices and their accessories may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products.

Automatic Answer

You can set your phone to automatically answer calls after two rings (four seconds) when connected to a car kit or headset.

Find the Feature

 > Settings
 > Other Settings

Press	To
1 	scroll to Car Settings or Headset
2 SELECT 	select the feature
3 	scroll to Auto Answer
4 CHANGE 	select Auto Answer
5 	scroll to On or Off
6 SELECT 	confirm the setting

Automatic Hands-Free

You can set your phone to automatically route calls to a car kit when it detects a connection.

Find the Feature

 > Settings
 > Other Settings
 > Car Settings
 > Auto Handsfree



Press	To
1 	scroll to On or Off
2 SELECT 	confirm the setting

Power-Off Delay

When your phone is connected to a car kit, you can set it to stay on for a period of time after you switch off the ignition. This prevents the phone from draining your vehicle battery, but leaves the phone on long enough that you do not have to re-enter your unlock code when making short stops.

Note: This feature may not work with all car ignition switches.

Caution: If you select **Continuous**, the phone does not power off when you turn off the ignition. Be careful not to drain your vehicle battery if you select this option.

Find the Feature

- ▶ **MENU** > **Settings**
- > **Other Settings**
- > **Car Settings**
- > **Power-Off Delay**

Press	To
1 	scroll to the time delay
2 SELECT ( <td>confirm your selection</td>	confirm your selection

Charger Time

When your phone is connected to a car kit, you can set it to charge itself for a specified time period after you switch off the ignition. This helps ensure that the phone battery gets fully charged while the vehicle is parked.

Note: This feature may not work with all car ignition switches.

Find the Feature

(MENU) > Settings
> Other Settings
> Car Settings
> Charger Time

Press	To
1 (○)	scroll to the charge time
2 SELECT (○)	confirm your selection



Data Calls



An optional Motorola Original™ data kit (which includes a cable connector) lets you transfer data between your phone and a computer, Palm OS® compatible device, or Microsoft Windows CE, Pocket PC, or Handheld PC device. You can:

- Synchronize phonebook and datebook information between your phone and a computer or PDA.
- Use your phone as a modem to connect to the Internet.
- Use your phone to send and receive data calls on your computer or hand-held device.

Making a Cable Connection

Install the Software

To transfer data between your phone and computer, you must install the software included with the Motorola Original data kit. See the data kit's user guide for more information.

Attach the Cable

Use a Motorola Original serial cable or Motorola Original USB cable to connect your phone to the external device.




Note: Not all devices are compatible with a cable connection. Check your computer or hand-held device to determine the type of cable you need.


Serial Cable

Do This

- 1 Plug the serial cable into the detachable head. Make sure that the Motorola logo on the detachable head and the metal shielding on the serial cable plug are both facing you.



- 2 With the Motorola logo and the phone both facing you, plug the detachable head into the phone's accessory connector port.




- 3 Plug the other end of the cable into the serial interface connection on the device and tighten the screws, if present.



USB Cable

Do This

- 1 Plug the end of the cable with the Motorola logo into the phone's accessory connector port. Make sure that the logo and the phone are both facing you.



- 2 Plug the other end—the USB connection—into the USB port on the external device.

Synchronizing Data

You can synchronize phonebook and datebook information between your phone, computer, and PDA with Starfish TrueSync® software, a Motorola accessory product. See the TrueSync user guide for more information.

Note: TrueSync software is designed to synchronize with basic features of many popular Personal Information Management (PIM) software and hardware products.

Sending a Data Call

Use this procedure to send data from a connected device.

Connect your phone to the device as described on pages 134-136 and do the following:

Do This	To
1 Check the phone	make sure that the phone is connected and powered on
2 Open the application on your computer	place the call through the application (such as dial-up-networking)
	Note: You cannot dial data numbers through your phone's keypad. You must dial them through your computer.
3 End the call from the connected device	close the call and connection when the transfer is complete

Receiving a Data Call

Use this procedure to transfer data to your computer or hand-held device. Connect your phone to the device as described on pages 134-136.

Set Up Your Phone

Find the Feature

() > Settings
 > Connection
 > Incoming Call

Do This	To
1 Press CHANGE (○)	select Next Call
2 Press 	scroll to Data In Only



Do This	To
3 Press SELECT (○)	set the call format
4 Connect your phone to the device	enable the data transfer

Note: You cannot answer incoming voice calls when your phone is in data mode. Any voice calls you receive are treated as unanswered calls. To return a voice call, reset your phone to voice mode as described on page 138.

Transfer the Data

Your phone notifies you when the data call arrives, and transfers the call to the connected device. Use the application running on the device to answer the call.

End the Data Connection

When the data transfer is complete, end the call from the connected device to close the connection.

Reset Normal Voice Operation

After making a data call, you must reset your phone to resume normal voice operations. You cannot receive voice calls when your phone is in data mode.

Find the Feature



- **MENU** > **Settings**
 - > **Connection**
 - > **Incoming Call**
 - > **Next Call > Normal**

Your phone also reverts to normal voice operations when you turn it off and then turn it back on.

Security



Security

Assigning a New Code or Password

Your phone's unlock code is originally set to 1234, and the security code is originally set to 000000. Your service provider may reset these numbers before you receive your phone.

If your service provider has *not* reset these numbers, we recommend that you change them to prevent other users from accessing your personal information. The unlock code must contain four digits, and the security code must contain six digits.

Notes:

- Your service provider may retain your phone's security code for customer service purposes. In this case, you will not be able to use phone features that require you to enter the security code.
- If the unlock code is the only code you can change, the **New Passwords** menu is not available. In this case, change the unlock code by selecting: **MENU** > **Settings** > **Security** > **Phone Lock** > **Unlock Code**.

To change a code or password:

Find the Feature



> **Settings** > **Security**
> **New Passwords**



Press	To
1	scroll to the code or password
2 CHANGE (select the code or password
3 keypad keys	enter your old code
4 OK (submit your old code
5 keypad keys	enter the new code
6 OK (assign the new code
7 keypad keys	re-enter the new code
8 OK (confirm the new code

If You Forget a Code or Password

If you forget your security code, contact your service provider.

If you forget your unlock code, try entering 1234 or the last four digits of your phone number. If that does not work, do the following at the **Enter Unlock Code** prompt:

Press	To
1	go to the unlock code bypass screen
2 keypad keys	enter your security code
3 OK (submit your security code

Locking and Unlocking Your Phone

You can lock your phone manually or set the phone to lock automatically whenever you turn it off.

To use a locked phone, you must enter the unlock code. A locked phone still rings or vibrates for incoming calls or messages, *but you must unlock it to answer*.

You can make emergency calls on your phone even when it is locked. For more information, see page 32.

Lock Your Phone Manually

Find the Feature



> Settings > Security
> Phone Lock
> Lock Now

Press	To
1 keypad keys	enter your unlock code
2 OK (○)	lock the phone

Set Your Phone to Lock Automatically

You can set your phone to lock every time you turn it off.

Find the Feature



> Settings > Security
> Phone Lock
> Automatic Lock > On

Press	To
1 keypad keys	enter your unlock code
2 OK (○)	activate automatic lock



Unlock Your Phone

At the **Enter Unlock Code** prompt:



Press	To
1 keypad keys	enter your unlock code
2 OK (○)	unlock your phone

Restricting Calls

You can stop all incoming and/or outgoing calls, or you can restrict them to the numbers stored in your phonebook.

Notes:

- You can make emergency calls when outgoing calls are restricted.
- Your phone still receives incoming text messages when incoming calls are restricted.
- When you restrict incoming calls to numbers stored in the phonebook, a valid incoming call may be restricted if caller ID information for the call is not available from the network.

Find the Feature



> **Settings > Security > Restrict Calls**

Press	To
1 keypad keys	enter your unlock code
2 OK (○)	open the restrict calls menu
3	scroll to Outgoing Calls or Incoming Calls
4 CHANGE (○)	select the option



Press	To
5 CHANGE (○)	change the Allow setting
6 ○	scroll to All, None, or Phonebook
7 SELECT (○)	select the allowed calls

Tip: The phonebook is not locked when you restrict outgoing calls to numbers stored in the phonebook. To prevent a user from adding (and then calling) a new phonebook entry, you may want to lock the phonebook. See the “Lock Application” item on page 56.

Activating Talk Secure

Your phone can attempt to send your calls using a high-security connection, to prevent others from intercepting them. For more information, see page 31.

Find the Feature

(> Settings > Security
> Talk Secure

Press	To
1 ○	scroll to Preferred or Off
2 SELECT (○)	switch talk secure on or off

Troubleshooting



Check these questions first if you have problems with your phone. If you need additional help, contact the Motorola Customer Call Center at 1-800-331-6456 (United States) or 1-800-461-4575 (Canada).

Question	Answer
Is your phone set up correctly?	Press . If you do not see your phone number, contact your service provider.
Is your battery charged? Do you see □ in the display?	The battery level indicator should have at least one segment showing (). If it does not, recharge your battery. See page 18.
Does the handset have a signal? Do you see ☰ in the display?	The signal strength indicator should have at least one segment showing (). If it does not, move to an area with a stronger signal to use your phone.
Is the earpiece volume too low?	While on a call, press the upper volume key on the side of your phone.



Question	Answer
Is the other party unable to hear you?	<p>Your phone may be muted. Press UNMUTE (○) if necessary to unmute the phone.</p> <p>Also, make sure that your phone's microphone is not blocked by its carrying case or a sticker.</p>
Has the phone been damaged, dropped, or gotten wet?	<p>Dropping your phone, getting it wet, or using a non-Motorola battery or battery charger can damage the phone. The phone's limited warranty does not cover liquid damage or damage caused from using non-Motorola accessories.</p>
Was a non-Motorola battery or battery charger used?	

The following refer to specific problems:

Problem	Solution
My phone was stolen. To whom should I report this?	<p>Report a stolen phone to the police and to your service provider (the company that sends you your monthly wireless service bill).</p>
I forgot my password.	<p>See page 140.</p>



Problem	Solution
I pressed the power key, but nothing happened.	Be sure to press and hold (the power key) until the display appears and you hear an alert. This could take several seconds. If nothing happens, check that a charged battery is installed. See page 17.
The display says: Enter Unlock Code. How do I unlock my phone?	Enter the factory-preset unlock code (1234), or the last four digits of your phone number. If this fails, call your service provider (the company that sends you your monthly wireless service bill).
My phone asks for an unlock code when I try to open a feature.	The application you want is locked. If you do not know the unlock code, see page 140.
My phone does not ring.	If you see or in the display, then the ringer is turned off. See page 99. Also, the ringer may be set to Silent even though your phone is set to an audible ring style. See page 99.



Problem	Solution
My phone rings even though I selected the Silent (or Vibrate) ring style.	The ringer may be set to play a tone even though your phone is set to a silent ring style. See page 99.
I tried to place a call and heard an alternating high/low tone.	Your call did not reach the wireless system. You may have dialed the number too soon after turning the phone on. Wait until you see the idle display before making a call.
I cannot send/receive calls.	<p>Make sure that you have a phone signal (see the “Signal Strength Indicator” item on page 25). Avoid electrical or radio interference, and obstructions such as bridges, parking garages, or tall buildings.</p> <p>Your phone also may have the Restrict Calls feature turned on. If you know the unlock code, you can change this setting in the security menu ( > Settings > Security).</p>



Problem	Solution
My phone has poor reception and drops calls.	<p>Make sure that your antenna is not bent or damaged.</p> <p>Also, make sure you have a phone signal (see the “Signal Strength Indicator” item on page 25). Stay clear of any obstructions such as bridges, parking garages, or tall buildings.</p>
I cannot hear others on my phone.	<p>While on a call, press the upper volume key. The display should show the volume increasing.</p> <p>Also, make sure that your phone’s earpiece is not blocked by its carrying case.</p>
I cannot open my message inbox.	<p>Before you can use text messages, you must set up the message inbox. See page 89.</p>
How do I see the calls I sent or received?	<p>To see the most recent calls you dialed or received:</p> <p style="text-align: center;">(MENU) > Recent Calls > Received Calls or Dialed Calls</p>

Problem	Solution
My phone will not send voicemail commands, passwords, or other codes.	<p>You must send PIN codes and passwords as DTMF tones while on a call. You can set your phone's DTMF tones to be Long, Short, or Off. If you have trouble sending numbers, try changing the DTMF setting.</p> <ol style="list-style-type: none"> <li data-bbox="369 433 806 467">1 From the idle display, press: <ul style="list-style-type: none"> <li data-bbox="438 488 492 518">(MENU) <li data-bbox="502 488 646 522">> Settings <li data-bbox="502 522 738 557">> Other Settings <li data-bbox="502 557 809 597">> Initial Setup > DTMF <li data-bbox="369 616 830 776">2 Press ☰ to scroll to Long or Short (some analog networks may not recognize short tones). <li data-bbox="369 795 820 835">3 Press SELECT (◎) to select it.
My phone's display is too dark.	<p>Use the Contrast feature to change the level of contrast in your display. See page 59.</p> <p>You can also use the Backlight feature to change the length of time that the display backlight stays on. See page 58.</p>





Problem	Solution
My battery didn't last as long as I expected. What can I do to extend battery life	Your battery's performance is affected by charge time, feature use, temperature changes, backlight use, and other factors. For tips on extending your battery life, see page 29.
I am unable to record a voice note, voice name, or voice shortcut.	Try moving to a quieter location to make your voice recording. Hold the phone about four inches (10 centimeters) from your mouth, and speak directly into the phone in a normal tone of voice.
My TTY device doesn't work with my phone.	Your phone must be set to a TTY mode for the phone to detect your TTY device. See page 128.
I plugged the data cable into my phone but my phone did not beep. How do I know if the data cable is ready to go?	The beep indicates that you are set up correctly. If you did not hear a beep, make sure that both ends of the data cable are connected—the smaller end to your phone and the larger end to your computer. Also, your computer may have deactivated the port to save power. Try opening an application that uses the port, like a fax or dial-up application, to automatically activate the port.



Problem	Solution
My phone beeped when I attached the data cable, but my data applications don't work.	<p>You must be in an area with digital coverage. Check your phone's display for the digital signal indicator (□).</p> <p>Some wireless networks may not support data transmission. If you see the digital indicator, but you are roaming on an unfamiliar network, this may be the case.</p> <p>Also, remember that data transmission usually requires a subscription. Call your service provider for more information.</p>
When sending data with the data cable, why does the computer show a connection rate of 19200 Kbps?	<p>19200 Kbps is the data transfer rate of the connection between your computer and the phone. The rate of the connection between your phone and the network is displayed on your phone, and will be either 14400 or 9600 Kbps.</p>
I can't end my data call by closing the application on my computer. What can I do?	<p>Try pressing END on your phone. Or try disconnecting the cable or turning off the phone. If possible, always close the connection through your computer, as these alternative methods may disrupt the application on your computer.</p>

Specific Absorption Rate Data

The Motorola V60i TDMA wireless phone meets the government's requirements for exposure to radio waves.

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission (FCC) of the U.S. Government and by Health Canada for Canada. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age or health.

The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC and by Health Canada is 1.6 W/kg.¹ Tests for SAR are conducted using standard operating positions accepted by the FCC and by Industry Canada with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station, the lower the power output.

Before a phone model is available for sale to the public in the U.S. and Canada, it must be tested and certified to the FCC and Industry Canada that it does not exceed the limit established by each government for safe exposure. The tests are performed in positions and locations (e.g., at the ear and worn on the body) reported to the FCC and available for review by Industry Canada. The highest SAR value for this model phone when tested for use at the ear is 1.27 W/kg, and when worn on the body, as described in this user guide, is 1.24 W/kg. (Body-worn measurements

differ among phone models, depending upon available accessories and regulatory requirements).²

While there may be differences between the SAR levels of various phones and at various positions, they all meet the governmental requirements for safe exposure.

Additional information on Specific Absorption Rates (SAR) can be found on the Cellular Telecommunications & Internet Association (CTIA) Web site:

<http://phonefacts.net>

or the Canadian Wireless Telecommunications Association (CWTA) Web site:

<http://www.cwta.ca>

1. In the United States and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in measurements.
2. The SAR information includes the Motorola testing protocol, assessment procedure, and measurement uncertainty range for this product.

**The U.S. Food and Drug
Administration's Center for
Devices and Radiological Health
Consumer Update on Mobile Phones**



FDA has been receiving inquiries about the safety of mobile phones, including cellular phones and PCS phones. The following summarizes what is known—and what remains unknown—about whether these products can pose a hazard to health, and what can be done to minimize any potential risk. This information may be used to respond to questions.

Why the concern?

Mobile phones emit low levels of radio frequency energy (i.e., radio frequency radiation) in the microwave range while being used. They also emit very low levels of radio frequency energy (RF), considered non-significant, when in the stand-by mode. It is well known that high levels of RF can produce biological damage through heating effects (this is how your microwave oven is able to cook food). However, it is not known whether, to what extent, or through what mechanism, lower levels of RF might cause adverse health effects as well. Although some research has been done to address these questions, no clear picture of the biological effects of this type of radiation has emerged to date. Thus, the available science does not allow us to conclude that mobile phones are absolutely safe, or that they are unsafe. However, the available scientific evidence does not demonstrate any adverse health effects associated with the use of mobile phones.

What kinds of phones are in question?

Questions have been raised about hand-held mobile phones, the kind that have a built-in antenna that is positioned close to the user's head during normal telephone conversation. These types of mobile phones are of concern because of the short distance between the phone's antenna—

the primary source of the RF—and the person's head. The exposure to RF from mobile phones in which the antenna is located at greater distances from the user (on the outside of a car, for example) is drastically lower than that from hand-held phones, because a person's RF exposure decreases rapidly with distance from the source. The safety of so-called "cordless phones," which have a base unit connected to the telephone wiring in a house and which operate at far lower power levels and frequencies, has not been questioned.

How much evidence is there that hand-held mobile phones might be harmful?

Briefly, there is not enough evidence to know for sure, either way; however, research efforts are on-going. The existing scientific evidence is conflicting and many of the studies that have been done to date have suffered from flaws in their research methods. Animal experiments investigating the effects of RF exposures characteristic of mobile phones have yielded conflicting results. A few animal studies, however, have suggested that low levels of RF could accelerate the development of cancer in laboratory animals. In one study, mice genetically altered to be predisposed to developing one type of cancer developed more than twice as many such cancers when they were exposed to RF energy compared to controls. There is much uncertainty among scientists about whether results obtained from animal studies apply to the use of mobile phones. First, it is uncertain how to apply the results obtained in rats and mice to humans. Second, many of the studies that showed increased tumor development used animals that had already been treated with cancer-causing chemicals, and other studies exposed the animals to the RF virtually continuously—up to 22 hours per day.

For the past five years in the United States, the mobile phone industry has supported research into the safety of mobile phones. This research has resulted in two findings in particular that merit additional study:

- 1 In a hospital-based, case-control study, researchers looked for an association between mobile phone use and either glioma (a type of brain cancer) or acoustic neuroma (a benign tumor of the nerve

sheath). No statistically significant association was found between mobile phone use and acoustic neuroma. There was also no association between mobile phone use and gliomas when all types of gliomas were considered together. It should be noted that the average length of mobile phone exposure in this study was less than three years.

When 20 types of glioma were considered separately, however, an association was found between mobile phone use and one rare type of glioma, neuroepitheliomatous tumors. It is possible with multiple comparisons of the same sample that this association occurred by chance. Moreover, the risk did not increase with how often the mobile phone was used, or the length of the calls. In fact, the risk actually decreased with cumulative hours of mobile phone use. Most cancer causing agents increase risk with increased exposure. An ongoing study of brain cancers by the National Cancer Institute is expected to bear on the accuracy and repeatability of these results.¹

2 Researchers conducted a large battery of laboratory tests to assess the effects of exposure to mobile phone RF on genetic material. These included tests for several kinds of abnormalities, including mutations, chromosomal aberrations, DNA strand breaks, and structural changes in the genetic material of blood cells called lymphocytes. None of the tests showed any effect of the RF except for the micronucleus assay, which detects structural effects on the genetic material. The cells in this assay showed changes after exposure to simulated cell phone radiation, but only after 24 hours of exposure. It is possible that exposing the test cells to radiation for this long resulted in heating. Since this assay is known to be sensitive to heating, heat alone could have caused the abnormalities to occur. The data already in the literature on the response of the micronucleus assay to RF are conflicting. Thus, follow-up research is necessary.²

FDA is currently working with government, industry, and academic groups to ensure the proper follow-up to these industry-funded research findings. Collaboration with the Cellular Telecommunications Industry Association (CTIA) in particular is expected to lead to FDA providing research

recommendations and scientific oversight of new CTIA-funded research based on such recommendations.

Two other studies of interest have been reported recently in the literature:

- 1 Two groups of 18 people were exposed to simulated mobile phone signals under laboratory conditions while they performed cognitive function tests. There were no changes in the subjects' ability to recall words, numbers, or pictures, or in their spatial memory, but they were able to make choices more quickly in one visual test when they were exposed to simulated mobile phone signals. This was the only change noted among more than 20 variables compared.³
- 2 In a study of 209 brain tumor cases and 425 matched controls, there was no increased risk of brain tumors associated with mobile phone use. When tumors did exist in certain locations, however, they were more likely to be on the side of the head where the mobile phone was used.

Because this occurred in only a small number of cases, the increased likelihood was too small to be statistically significant.⁴

In summary, we do not have enough information at this point to assure the public that there are, or are not, any low incident health problems associated with use of mobile phones. FDA continues to work with all parties, including other federal agencies and industry, to assure that research is undertaken to provide the necessary answers to the outstanding questions about the safety of mobile phones.

What is known about cases of human cancer that have been reported in users of hand-held mobile phones?

Some people who have used mobile phones have been diagnosed with brain cancer. But it is important to understand that this type of cancer also occurs among people who have not used mobile phones. In fact, brain cancer occurs in the U.S. population at a rate of about 6 new cases per 100,000 people each year. At that rate, assuming 80 million users of

mobile phones (a number increasing at a rate of about 1 million per month), about 4800 cases of brain cancer would be expected each year among those 80 million people, whether or not they used their phones. Thus it is not possible to tell whether any individual's cancer arose because of the phone, or whether it would have happened anyway. A key question is whether the risk of getting a particular form of cancer is greater among people who use mobile phones than among the rest of the population. One way to answer that question is to compare the usage of mobile phones among people with brain cancer with the use of mobile phones among appropriately matched people without brain cancer. This is called a case-control study. The current case-control study of brain cancers by the National Cancer Institute, as well as the follow-up research to be sponsored by industry, will begin to generate this type of information.

What is FDA's role concerning the safety of mobile phones?

Under the law, FDA does not review the safety of radiation-emitting consumer products such as mobile phones before marketing, as it does with new drugs or medical devices. However, the agency has authority to take action if mobile phones are shown to emit radiation at a level that is hazardous to the user. In such a case, FDA could require the manufacturers of mobile phones to notify users of the health hazard and to repair, replace or recall the phones so that the hazard no longer exists.

Although the existing scientific data do not justify FDA regulatory actions at this time, FDA has urged the mobile phone industry to take a number of steps to assure public safety. The agency has recommended that the industry:

- support needed research into possible biological effects of RF of the type emitted by mobile phones
- design mobile phones in a way that minimizes any RF exposure to the user that is not necessary for device function

- cooperate in providing mobile phone users with the best possible information on what is known about possible effects of mobile phone use on human health

At the same time, FDA belongs to an interagency working group of the federal agencies that have responsibility for different aspects of mobile phone safety to ensure a coordinated effort at the federal level. These agencies are:

- National Institute for Occupational Safety and Health
- Environmental Protection Agency
- Federal Communications Commission
- Occupational Health and Safety Administration
- National Telecommunications and Information Administration

The National Institutes of Health also participates in this group.

In the absence of conclusive information about any possible risk, what can concerned individuals do?

If there is a risk from these products—and at this point we do not know that there is—it is probably very small. But if people are concerned about avoiding even potential risks, there are simple steps they can take to do so. For example, time is a key factor in how much exposure a person receives. Those persons who spend long periods of time on their hand-held mobile phones could consider holding lengthy conversations on conventional phones and reserving the hand-held models for shorter conversations or for situations when other types of phones are not available.

People who must conduct extended conversations in their cars every day could switch to a type of mobile phone that places more distance between their bodies and the source of the RF, since the exposure level drops off dramatically with distance. For example, they could switch to:

- a mobile phone in which the antenna is located outside the vehicle

- a hand-held phone with a built-in antenna connected to a different antenna mounted on the outside of the car or built into a separate package
- a headset with a remote antenna to a mobile phone carried at the waist

Again, the scientific data do not demonstrate that mobile phones are harmful. But if people are concerned about the radio frequency energy from these products, taking the simple precautions outlined above can reduce any possible risk.

Where can I find additional information?

For additional information, see the following Web sites:

Federal Communications Commission (FCC) RF Safety Program (select "Information on Human Exposure to RF Fields from Cellular and PCS Radio Transmitters"):

<http://www.fcc.gov/oet/rfsafety>

World Health Organization (WHO) International Commission on Non-Ionizing Radiation Protection (select Qs & As): <http://www.who.int/emf>

United Kingdom, National Radiological Protection Board:
<http://www.nrp.org.uk>

Cellular Telecommunications Industry Association (CTIA):
<http://www.wow-com.com>

U.S. Food and Drug Administration (FDA) Center for Devices and Radiological Health:
<http://www.fda.gov/cdrh/consumer/>

1. Muscat et al. Epidemiological Study of Cellular Telephone Use and Malignant Brain Tumors. In: State of the Science Symposium;1999 June 20; Long Beach, California.
2. Tice et al. Tests of mobile phone signals for activity in genotoxicity and other laboratory assays. In: Annual Meeting of the Environmental Mutagen Society; March 29, 1999, Washington, D.C.; and personal communication, unpublished results.
3. Preece, AW, Iwi, G, Davies-Smith, A, Wesnes, K, Butler, S, Lim, E, and Varey, A. Effect of a 915-MHz simulated mobile phone signal on cognitive function in man. *Int. J. Radiat. Biol.*, April 8, 1999.
4. Hardell, L, Nasman, A, Pahlson, A, Hallquist, A and Mild, KH. Use of cellular telephones and the risk for brain tumors: a case-control study. *Int. J. Oncol.*, 15: 113-116, 1999.

Motorola Limited Warranty for the United States and Canada

What Does this Warranty Cover?

Subject to the exclusions contained below, Motorola, Inc. warrants its telephones, pagers, and consumer and professional two-way radios (excluding commercial, government or industrial radios) that operate via Family Radio Service or General Mobile Radio Service, Motorola-branded or certified accessories sold for use with these Products ("Accessories") and Motorola software contained on CD-ROMs or other tangible media and sold for use with these Products ("Software") to be free from defects in materials and workmanship under normal consumer usage for the period(s) outlined below. This limited warranty is a consumer's exclusive remedy, and applies as follows to new Motorola Products, Accessories and Software purchased by consumers in the United States or Canada, which are accompanied by this written warranty:

Products and Accessories

Products Covered	Length of Coverage
Products and Accessories as defined above, unless otherwise provided for below.	One (1) year from the date of purchase by the first consumer purchaser of the product unless otherwise provided for below.
Decorative Accessories and Cases. Decorative covers, bezels, PhoneWrap™ covers and cases.	Limited lifetime warranty for the lifetime of ownership by the first consumer purchaser of the product.
Monaural Headsets. Ear buds and boom headsets that transmit mono sound through a wired connection.	Limited lifetime warranty for the lifetime of ownership by the first consumer purchaser of the product.

Products Covered	Length of Coverage
Consumer and Professional Two-Way Radio Accessories.	Ninety (90) days from the date of purchase by the first consumer purchaser of the product.
Products and Accessories that are Repaired or Replaced.	The balance of the original warranty or for ninety (90) days from the date returned to the consumer, whichever is longer.

Exclusions

Normal Wear and Tear. Periodic maintenance, repair and replacement of parts due to normal wear and tear are excluded from coverage.

Batteries. Only batteries whose fully charged capacity falls below 80% of their rated capacity and batteries that leak are covered by this limited warranty.

Abuse & Misuse. Defects or damage that result from: (a) improper operation, storage, misuse or abuse, accident or neglect, such as physical damage (cracks, scratches, etc.) to the surface of the product resulting from misuse; (b) contact with liquid, water, rain, extreme humidity or heavy perspiration, sand, dirt or the like, extreme heat, or food; (c) use of the Products or Accessories for commercial purposes or subjecting the Product or Accessory to abnormal usage or conditions; or (d) other acts which are not the fault of Motorola, are excluded from coverage.

Use of Non-Motorola Products and Accessories. Defects or damage that result from the use of Non-Motorola branded or certified Products, Accessories, Software or other peripheral equipment are excluded from coverage.

Unauthorized Service or Modification. Defects or damages resulting from service, testing, adjustment, installation, maintenance, alteration, or modification in any way by someone other than Motorola, or its authorized service centers, are excluded from coverage.

Altered Products. Products or Accessories with (a) serial numbers or date tags that have been removed, altered or obliterated; (b) broken seals or that show evidence of tampering; (c) mismatched board serial numbers; or (d) nonconforming or non-Motorola housings, or parts, are excluded from coverage.

Communication Services. Defects, damages, or the failure of Products, Accessories or Software due to any communication service or signal you may subscribe to or use with the Products Accessories or Software is excluded from coverage.

Software

Products Covered	Length of Coverage
Software. Applies only to physical defects in the media that embodies the copy of the software (e.g. CD-ROM, or floppy disk).	Ninety (90) days from the date of purchase.

Exclusions

Software Embodied in Physical Media. No warranty is made that the software will meet your requirements or will work in combination with any hardware or software applications provided by third parties, that the operation of the software products will be uninterrupted or error free, or that all defects in the software products will be corrected.

Software NOT Embodied in Physical Media. Software that is not embodied in physical media (e.g. software that is downloaded from the internet), is provided "as is" and without warranty.

Who is Covered?

This warranty extends only to the first consumer purchaser, and is not transferable.

What Will Motorola Do?

Motorola, at its option, will at no charge repair, replace or refund the purchase price of any Products, Accessories or Software that does not conform to this warranty. We may use functionally equivalent

reconditioned/refurbished/pre-owned or new Products, Accessories or parts. No data, software or applications added to your Product, Accessory or Software, including but not limited to personal contacts, games and ringer tones, will be reinstalled. To avoid losing such data, software and applications please create a back up prior to requesting service.

How to Obtain Warranty Service or Other Information?

USA	Phones 1-800-331-6456 Two-Way Radios 1-800-353-2729 Pagers 1-800-548-9954
Canada	All Products 1-800-461-4575
TTY	1-888-390-6456
For Accessories and Software , please call the telephone number designated above for the product with which they are used.	

You will receive instructions on how to ship the Products, Accessories or Software, at your expense, to a Motorola Authorized Repair Center. To obtain service, you must include: (a) a copy of your receipt, bill of sale or other comparable proof of purchase; (b) a written description of the problem; (c) the name of your service provider, if applicable; (d) the name and location of the installation facility (if applicable) and, most importantly; (e) your address and telephone number.

What Other Limitations Are There?

ANY IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY, OTHERWISE THE REPAIR, REPLACEMENT, OR REFUND AS PROVIDED UNDER THIS EXPRESS LIMITED WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER, AND IS PROVIDED IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. IN NO EVENT SHALL MOTOROLA BE LIABLE, WHETHER IN CONTRACT OR TORT

(INCLUDING NEGLIGENCE) FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT, ACCESSORY OR SOFTWARE, OR FOR ANY INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES OF ANY KIND, OR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR DATA, SOFTWARE OR APPLICATIONS OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE ABILITY OR INABILITY TO USE THE PRODUCTS, ACCESSORIES OR SOFTWARE TO THE FULL EXTENT THESE DAMAGES MAY BE DISCLAIMED BY LAW.

Some states and jurisdictions do not allow the limitation or exclusion of incidental or consequential damages, or limitation on the length of an implied warranty, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state or from one jurisdiction to another.

Laws in the United States and other countries preserve for Motorola certain exclusive rights for copyrighted Motorola software such as the exclusive rights to reproduce and distribute copies of the Motorola software. Motorola software may only be copied into, used in, and redistributed with, the Products associated with such Motorola software. No other use, including without limitation disassembly of such Motorola software or exercise of the exclusive rights reserved for Motorola, is permitted.

Product Registration

Online Product Registration:

<http://www.motorola.com/warranty>

Product registration is an important step toward enjoying your new Motorola product. Registering helps us facilitate warranty service, and permits us to contact you should your product require an update or other service. Registration is for U.S. residents only and is not required for warranty coverage.

Please retain your original dated sales receipt for your records. For warranty service of your Motorola Personal Communications Product you will need to provide a copy of your dated sales receipt to confirm warranty status.

Thank you for choosing a Motorola product.

Export Law Assurances

This product is controlled under the export regulations of the United States of America and Canada. The Governments of the United States of America and Canada may restrict the exportation or re-exportation of this product to certain destinations. For further information contact the U.S. Department of Commerce or the Canadian Department of Foreign Affairs and International Trade.

Index

A

accessories
optional 10, 38, 84, 114, 128, 130, 134
standard 17
accessory connector port 1
active line indicator
defined 25
illustration 24
Add Digits feature 63
alarm 79, 81
alert
defined 99
reminders, turning on/off 107
selecting 99–100
turning off 33
analog signal indicator
defined 25
illustration 24
animation 59
answering a call 22
application, locking 56
appointments. *See*
datebook
Attach Number feature 35, 63

B

backlight 58
battery
car kit charger time 132
charging 18–19
extending battery life 26, 29–30, 58, 59
installing 17–18
level indicator 19, 24, 25
meter 55
blackjack 122–124
block cursor, defined 42
browse text mode 43

C

calculator 119–121
calendar. *See* datebook
call
adding digits after phone number 63
alert, selecting 99–100
alert, turning off 33
answer options 56
answering 22
call waiting 37
calling card 71
canceling 33
datebook, opening 38

deleting 62–64
dialed calls list 36, 38,
62–64
dialing 22
dialing a recent call 62–
64
emergency number 32
ending 22
in-call timer 56
making 22
message center,
accessing 38
muting 38
prefix digits, inserting 35
privacy 31, 143
received calls list 36, 38,
62–64
receiving 22
recent calls 62–64
restricting 142–143
ring style, setting 99
ring style, setting in
external display 28
secure connection 31,
143
speakerphone, activating
38
storing 62–64
three-way call 37
timing 65–66
unanswered call 28, 32
voice dial 36
call timers 65–66
call waiting 37
caller ID 31, 32
calling card call 71
calling line identification.
See caller ID
car kit
automatic answer 131
automatic hands-free
131
charger time 132
power-off delay 132
clock 24
codes
changing 139–140
default 21, 139
if you forget a code/
password 140
computer
synchronizing data 78,
83
contrast, display 59
convertible covers 19–20
currency converter 121
cursor 42

D

data call
making 134–138
date, setting 58

datebook
adding an event 81
alarm 81
calendar 79
changing event
 information 81
copying an event 82
day view 80
deleting an event 83
event reminders, turning
 on/off 107
event view 80
reminders 81
synchronizing 136
synchronizing entries 83
week view 79
deleting a call 62–64
dialed calls list 36, 38, 62–
 64
dialing a number 22
digital signal indicator
 defined 25
 illustration 24
display
 animation 59
 backlight 58
 contrast 59
 described 24–26
 idle display 24
 illustration 24
 language 59
 zoom setting 58
 zooming in/out 26
drafts folder 54
DTMF tones 59, 63, 149
 sending 38, 64

E

earpiece
 illustration 1
volume, adjusting 27

email
 address, storing in
 phonebook 68–70
email, sending 73, 94–96
emergency number 32
end key 39
 functions 1, 22
ending a call 22

Enter Unlock Code message
 140, 142

event alert 99–100

exchange rate, calculating
 121

external device
 synchronizing data 78,
 83

external display 28

F

factory settings, resetting
 59–60

falling numbers 124–125

flashing cursor, defined 42
flip
 external display and 28
 open to answer call 56
 turning the phone on 21
FM Stereo Radio Headset
 53, 84–86

G

games 122

H

hands-free mode
 automatic answer 131
 automatic call routing
 131
 charger time 132
 defined 130
 external display and 29
 power-off delay 132
 speakerphone, activating
 38

headset

 automatic answer 131
 FM Stereo Radio Headset
 53, 84–86
 use with external display
 29

headset jack 1
high-security connection
 31, 143

I

idle display, defined 24
in use indicator
 defined 25
 illustration 24
inbox, text message 89–90
in-call timer 56
incoming call
 canceling 33
Incoming Call message 31
indicators
 active line 24, 25
 battery level 19, 24, 25
 digital/analog signal 24,
 25
 in use 24, 25
 loud ring style 26, 99
 menu 24, 25
 message waiting 24, 25,
 90, 91
 missed call 32
 ring style 24, 26, 99
 roam 24, 25
 signal strength 24, 25
 silent alert 26
 silent ring style 26, 99
 soft ring style 26, 99
 vibrate and ring style 26,
 99
 vibrate style 26, 99

voice message waiting 24, 25, 88
voice name 67
iTAP software 48–51

K

key end 1, 22, 39
left soft key 1, 24, 39, 127
menu 1, 10, 25, 39
power 1, 21
right soft key 1, 24, 39, 127
scroll 1, 39
send 1, 22, 62
smart 1, 27–28
smart key 127
voice 1, 72, 113
volume control 1, 27, 39

keypad answering calls 56
volume, setting 101

L

language, setting 59
left soft key customizing 127
functions 1, 24, 39
Line Not Secure message 32

lock applications 56
phone 141–142
voice notes 117

lock application feature 56
loud ring style indicator 26, 99

Low **B**attery message 25

M

making a call 22
master clear 60
master reset 59
Memory is **F**ull! message 91
Memory is **L**ow! message 91

menu **C**alculator Menu 119
Datebook Menu 79, 80
Dialing Menu 35, 64
entering text 41–42, 43–51
features 52–61
language, setting 59
Last **C**alls Menu 63–64
lists 40
locking applications 56
My **T**ones Menu 106, 107
navigating 10, 39
personalizing 127
Phonebook Menu 67

Quick Note Menu 97
rearranging features 127
scroll feature 58
Text Msg Menu 92–93
using features 10, 40–42
Voice Notes Menu 114,
 115, 116
menu indicator
 defined 25
 illustration 24
menu key 1, 10, 25, 39
message
 deleting, text 91–93
 dialing number from 34
 drafts folder 54
 locking, text 91–93
 outbox 53, 98
 quick note 97
 reading, text 91–93
 receiving, text 90–91
 reminders, receiving 88,
 90
 reminders, turning on/off
 107
 sending 35, 94–96
 sound 93–94
 status 98
 text 89–98
text message inbox setup
 89–90
voicemail 87–88

message waiting indicator
 defined 25
 displayed 90
 flashing 91
 illustration 24
microphone 1
missed call indicator 32
Missed Call message 32
missed call, dialing 36
Missed Calls message 28
muting a call 38
my telephone number 3,
 23, 38, 55
my tones 101–107
 using 101–107

N

network settings 60
notepad
 defined 64
 entering digits 64
 retrieving digits 64
number, viewing your own
 3, 55
numeric text mode 43

O

one-touch dial
 defined 34
 using 34
voicemail number 34

optional accessory, defined 10
optional feature, defined 10
outbox 53, 98

P

passwords. *See* codes
pause character 35, 71
phone
 active line indicator 25
 alert, turning off 33
 answer options 56
 codes 139–140
 erase user-entered information 60
 feature specifications 38
 flip 21
 information 38
 locking 141–142
 reset all options 59
 secure connection 31, 143
 security code 139
 specifications 38
 turning on/off 21
 unlock code 21, 139, 140
 unlocking 21, 141–142
phone number
 active line indicator 25
 active phone line, changing 55
 adding digits after 63

attaching to prefix digits 35
attaching two numbers 63
long numbers, storing 74–75
redialing 31
seeing your own 23, 38
sending text message to 35
storing in phonebook 68–70
viewing your own 3, 55
voice dial 36
phonebook
 attaching two numbers 63
capacity, checking 76
deleting an entry 75
dialing a number 73
editing an entry 75
email address 67
entry details 67
entry name 67
long numbers 74–75
number type indicator 67
one-touch dial 34
phone number 67
prefix digits, inserting 35
primary number, setting 76

ringer ID, activating/
deactivating 100
ringer ID, defined 70, 100
ringer ID, setting 70
sending an email 73
sorting entries 77
speed dial number 67, 69
speed dial number,
defined 34
speed dial, using 34
storing an entry 68–70
synchronizing 136
synchronizing entries 78
voice name entry 72
voice name indicator 67
PIN code 70
power key 1, 21
predictive text entry 48–51
privacy, call 31, 143

Q

quick note 97
defined 89

R

radio 84–86
received calls list 36, 38,
62–64
recent calls 62–64
redial
busy number 31
reminders

datebook 81
defined 107
text message 90
turning on/off 107
voicemail message 88
restricting calls 142–143
right soft key
customizing 127
functions 1, 24, 39
ring alert
selecting 99–100
turning off 33
ring style
customizing 99–101
defined 99
indicators 26, 99
setting 99
setting in external display
28
ring style indicator
defined 26, 99
illustration 24
ringer
volume, adjusting 27
volume, setting 101
ringer ID
activating/deactivating
100
defined 70, 100
listed in phonebook entry
67

setting for phonebook entry 70

roam indicator defined 25 illustration 24

S

scroll feature 58

scroll key 1, 39

secure connection 31, 143

security code changing 139–140

send key 1, 22, 62

short message service. *See* text message

shortcuts creating 110–111 standard 109 using 111–112

signal strength indicator defined 25 illustration 24

silent alert indicator 26

silent ring style indicator 26, 99

smart key customizing 127 defined 27–28 functions 27–28 illustration 1

SMS. *See* text message

soft keys customizing 127 functions 24, 39 illustration 1 labels 24

soft ring style indicator 26, 99

sound storing 93–94

speakerphone, activating 38

speed dial changing number 69 number, defined 34 sorting phonebook entries by 77 using 34

standby time defined 27 increasing 30

status light 1, 26–27, 58

storing a call 62–64

symbol text mode 47–48

symbols, entering 47–48

synchronizing data 78, 83

T

Talk Secure feature 31, 143

tap method text entry 44–46

telephone number, viewing your own 3, 55

text
block cursor 42
browse mode 43
character chart 46
entering from keypad 43–51
entry mode, changing 43
flashing cursor 42
iTAP software predictive text entry 48–51
numeric mode 43
symbol chart 47
symbol mode 47–48
tap method 44–46
text message
defined 89
deleting 91–93
dialing number from 34
drafts folder 54
inbox setup 89–90
locking 91–93
outbox 53
quick note 97
reading 91–93
receiving 90–91
reminders 90
sending 35, 94–96
sound 93–94
status 98
text message inbox 89–90
text mode, changing 43

three-way call 37
time, setting 58
timers 65–66
travel charger, using 18
TrueSync 78, 83, 136
TTY device 38, 128–130

U

unlock
phone 141–142
unlock code 140
bypassing 140
changing 139–140
entering 21, 141, 142

V

vibrate alert
selecting 99–100
turning off 33
vibrate and ring style
indicator 26, 99
vibrate ring style
setting 99
setting in external display 28
vibrate style
indicator 26, 99
video poker 125–126
voice dial
dialing a number 36, 73
recording voice name 72

voice key
dialing a number 36
functions 1
recording a voice name
72
recording a voice note
113
voice message waiting
indicator 24, 25, 88
voice name
defined 72
phonebook indicator 67
recording 72
voice notes 113–118
voice shortcut
creating 110–111
defined 110
using 112
voicemail
dialing with one-touch dial
34
reminders, turning on/off
107
using 87–88
volume
earpiece 27
keypad 101
ringer 27, 101
volume keys 1, 27, 39

W

wait character 35, 71
warranty 162–166

Z

zoom setting 58
zooming in/out 26



MOTOROLA

Wireless Phone Safety Tips

"Safety is your most important call!"

Your Motorola wireless telephone gives you the powerful ability to communicate by voice—almost anywhere, anytime, wherever wireless phone service is available and safe conditions allow. But an important responsibility accompanies the benefits of wireless phones, one that every user must uphold.

When driving a car, driving is your first responsibility. If you find it necessary to use your wireless phone while behind the wheel of a car, practice good common sense and remember the following tips:

- 1 Get to know your Motorola wireless phone and its features such as speed dial and redial. If available, these features help you to place your call without taking your attention off the road.



- 2 When available, use a hands-free device.** If possible, add an additional layer of convenience to your wireless phone with one of the many Motorola Original™ hands-free accessories available today.
- 3 Position your wireless phone within easy reach.** Be able to access your wireless phone without removing your eyes from the road. If you receive an incoming call at an inconvenient time, if possible, let your voice mail answer it for you.
- 4 Let the person you are speaking with know you are driving; if necessary, suspend the call in heavy traffic or hazardous weather conditions.** Rain, sleet, snow, ice, and even heavy traffic can be hazardous.
- 5 If you receive an incoming call at an inconvenient time do not take notes or look up phone numbers while driving.** Jotting down a “to do” list or going through your address book takes attention away from your primary responsibility—driving safely.
- 6 Dial sensibly and assess the traffic; if possible, place calls when you are not moving or before pulling into traffic.** Try to plan calls when your car will be stationary. If you need to make a call while moving, dial only a few numbers, check the road and your mirrors, then continue.
- 7 Do not engage in stressful or emotional conversations that may be distracting.** Make people you are talking with aware you are driving and suspend conversations which have the potential to divert your attention away from the road.



- 8 Use your wireless phone to call for help.** Dial 9-1-1 or other local emergency number in the case of fire, traffic accident or medical emergencies.*
- 9 Use your wireless phone to help others in emergencies.** If you see an auto accident, crime in progress or other serious emergency where lives are in danger, call 9-1-1 or other local emergency number, as you would want others to do for you.*
- 10 Call roadside assistance or a special non-emergency wireless assistance number when necessary.** If you see a broken-down vehicle posing no serious hazard, a broken traffic signal, a minor traffic accident where no one appears injured, or a vehicle you know to be stolen, call roadside assistance or other special non-emergency wireless number.*

* Wherever wireless phone service is available.

Check the laws and regulations on the use of wireless telephones and their accessories in the areas where you drive. Always obey them. The use of these devices may be prohibited or restricted in certain areas.



For more information,
please call
1-888-901-SAFE
or visit the
CTIA Web site at
[www.wow-com.com™](http://www.wow-com.com)



motorola.com

8988485L49-O